SOUTHERN PACIFIC COMPANY

(PACIFIC LINES)

SUPPLEMENT No. 1 TO TIMETABLE No. 183

FOR THE

LOS ANGELES DIVISION

SUPERSEDING PAGES 2 AND 3

Effective Sunday, April 14, 1946, at 12:01 A. M.

PACIFIC STANDARD TIME

For the government and information of employes only.

J. W. CORBETT, *General Manager.*	R. E. HALLAWELL, H. R. HUGHES, *Assistant General Managers.*	G. C. BAKER, *General Superintendent of Transportation.*	C. H. GRANT, *Superintendent of Transportation.*	H. R. GERNREICH, *Superintendent.*

VENTURA SUBDIVISION

Rules 86 and 93. Between Santa Barbara and Burbank Jct., Second and inferior class trains, extra trains and engines, except trains handling passenger equipment only, must clear the time of Nos. 96, 97, 98 and 99 not less than 10 minutes, and must be clear of main track and insulated joints at meeting and passing points for Nos. 96, 97, 98 and 99.

Rule 5. Schedule time and train orders at Burbank Jct. apply at end of double track.

Maximum speed provided for passenger trains, other than streamlined trains, will apply to Nos. 373 and 374 when those trains consist entirely of passenger equipment, or cars with steel wheels, including box cars with steel wheels, or caboose with steel wheels, except that maximum speed of 60 MPH must not be exceeded.

Between Mission Tower and Dayton Ave. Tower, via East Bank Jct., trains or engines may use main tracks, in either direction, being governed by signal indication.

Trains or engines stopped by interlocking signals at signal bridges 3, 4, or 6, will, if signal does not clear, call signal operator on telephone located on signal bridge.

Rules and regulations of Los Angeles Union Passenger Terminal must be observed between terminal limits and end of tracks at Los Angeles.

Revenue passenger trains, except exclusively Government business, must stop at Glendale.

No. 72 stop daily except Sunday at Carpinteria to receive U. S. mail.

No. 72 Vega—Stop to dispatch mail.

Additional flag stops to receive or discharge passengers:

No. 70 Camarillo—Receive revenue to Los Angeles or beyond.

No. 76 Ventura—Discharge revenue from or beyond Salinas.

No. 26 Burbank—Discharge from Fresno or beyond.

No. 72 Los Angeles Yard — Discharge D.H. trainmen and enginemen.

Dulah Siding will not hold more than 15 passenger cars and one engine.

EASTWARD

Supplement No. 1
to
Time Table No. 183
April 14, 1946

Capacity of Sidings in Car Lengths	SECOND CLASS			FIRST CLASS										Distance from San Francisco	STATIONS	
	832	**448**	**834**	**72**	**96**	**52**	**98**	**76**	**60**	**374**	**26**	**70**	**56**			
	Freight	Freight	**Freight**	Passenger	Noon Daylight	**San Joaquin**	Morning Daylight	**Lark**	**West Coast**	C. M. E.	**Owl**	Coaster	**Tehachapi**			
	Leave Daily	**Leave Daily Ex. Monday**	**Leave Daily**	Leave Daily	**Leave Daily**	**Leave Daily**	**Leave Daily**	**Leave Daily**	**Leave Daily**	Leave Daily Ex. Sun. & Mon.	**Leave Daily**	**Leave Daily**	Leave Daily			
BKWOTP S. Barbara yd.	7.25 AM		11.25 PM	8.00 PM	7.33 PM		**3.40 PM**	**6.10 AM**		5.40 AM		5.10 AM		370.7	TO-R **SANTA BARBARA** E. 1.2	D.T.
	7.32		**11.32**	8.05	7.37		3.43	6.15		5.45		5.15		371.9	**EAST SANTA BARBARA** E. 4.5	
106 P	7.42		11.42	8.13	7.45		3.50	6.23		5.53		5.23		377.3	**ORTEGA** E. 4.6	
40 P	7.50		11.50	f 8.19	7.50		3.55	6.28		5.58		5.28		381.2	TO **CARPINTERIA** E. 2.1	
40 P	7.54		11.54					6.32		6.01		5.31		383.4	**WAVE** E. 2.3	
39 P	7.59		11.59 PM	8.25	7.56		**4.01**	**6.36**		6.05		5.35		385.7	**PUNTA** E. 3.1	
105 P	8.06		12.06 AM	8.30	8.00		**4.05**	**6.40**		6.09		5.39		388.6	**SEACLIFF** E. 4.1	
29 P	8.15		12.15	8.35	8.05		**4.10**	**6.46**		6.14		5.44		392.9	**DULAH** E. 4.7	
Yd. Lts. P														397.3	**VENTURA JCT.** E. 0.7	
123 WP	8.25		12.25	s 8.48	8.12		**4.18**	**6.56**		6.22		s 5.54		398.2	TO **VENTURA** E. 4.7	
40 YP	8.33		12.33	8.55				**7.02**		6.28		6.00		403.2	**MONTALVO** E. 4.5	
Yard Limits 107 BKWOP	**8.58**		12.43	s 9.10	8.24		**4.29**	**7.09**		6.34		s 6.08		407.8	TO **OXNARD** E. 4.6	
66 P	9.08		12.53	**9.22**	8.29		**4.34**	**7.15**		6.40		6.13		412.1	**LEESDALE** E. 4.3	
117 P	**9.31**		1.02	s **9.30**	8.33		**4.39**	**7.21**		6.46		6.18		416.6	TO **CAMARILLO** E. 3.4	
43 P	9.40		1.10	9.34	8.37		**4.42**	**7.26**		6.50		6.22		419.8	**SOMIS** E. 3.1	
65 P	9.50		1.20	9.38	8.40		**4.45**	**7.31**		6.54		6.27		422.9	**LAGOL** E. 3.8	
103 WP	10.05		**1.37**	f 9.44	8.45		**4.49**	**7.37**		7.00		6.33		427.1	TO **MOORPARK** E. 5.2	
69 P	10.20		1.50	9.52	8.50			**7.46**		7.08		6.41		432.2	**STRATHEARN** E. 5.0	Automatic Block System
105 P	**10.35**		2.04	f **10.05**	**8.55**		5.00	**7.55**		7.16		6.49		437.5	TO **SANTA SUSANA** E. 3.7	
72 P	10.49		2.18	10.13	**8.59**		5.05	**8.02**		7.22		6.55		441.0	**HASSON** E. 4.8	
85 WYP	11.04		2.33	f 10.21	9.06		5.12	8.09		7.30		7.03		445.5	TO **CHATSWORTH** E. 4.2	
E 56 W 56 P	11.12		2.41	f 10.28	9.10		5.16	8.15		**7.35**		7.08		449.9	TO **NORTHRIDGE** E. 4.2	
E 38 W 44 P	11.20		2.49	10.33	9.14		5.20	8.20		7.40		7.14		454.1	**RAYMER** E. 4.6	
103 P	11.28		2.57	10.37	9.18		5.24	8.25		7.45		**7.18**		458.4	**HEWITT** E. 3.4	
Los Angeles yard: 104 IP	11.36 AM	4.25 AM	3.05	10.42	9.23	7.10 PM	**5.28**	8.30	8.15 AM	7.50	7.45 AM	7.24	5.25 AM	462.7 471.6	TO **BURBANK JCT.** E. 1.8	Double Track
YP				f 10.44									f 5.27	472.1	**BURBANK** E. 5.0	
P				s 10.55	s 9.35	s 7.20	s **5.40**	s **8.42**	s 8.25		s 7.55	s 7.38	s 5.37	477.1	**GLENDALE** E. 0.2	
I														477.3	**GLENDALE TOWER** **P. E. Ry. CROSSING** E. 1.2	
														478.5	**ARROYO JCT.** E. 1.2	
BKW OYP	12.05 PM	5.00 AM	3.30 AM							8.15 AM			f	479.7	TO-R **LOS ANGELES YARD** E. 0.9	
Interlocking: I				11.06	9.43	7.28	**5.48**	**8.49**	8.33		8.03	7.46	5.46	480.6	**DAYTON AVE. TOWER** E. 0.9	
														481.5	**GLENDALE JCT.** E. 0.4	
				11.11	9.48	7.33	**5.53**	**8.53**	8.37		8.07	7.50	5.50	481.9	**EAST BANK JCT.** E. 0.15	
														482.05	**U. P. R. R. CROSSING** E. 0.13	
I					9.50	7.35	**5.55**	**8.55**	8.39		8.09	7.54	5.54	482.18	**A. T. & S. F. Ry. CROSSING** **MISSION TOWER** E. 0.62	
BKW IYP				s 11.20 PM	s 9.55 PM	s 7.40 PM	s **6.00 PM**	s **9.00 AM**	s 8.45 AM		s 8.15 AM	s 8.00 AM	s 6.00 AM	482.8	TO-R **LOS ANGELES** **LAUPT**	
	Arrive Daily	**Arrive Daily Ex. Monday**	**Arrive Daily**	**Arrive Daily**	**Arrive Daily**	**Arrive Daily**	**Arrive Daily**	**Arrive Daily**	Arrive Daily	**Arrive Daily Ex. Sun. & Mon.**	Arrive Daily	**Arrive Daily**	**Arrive Daily**		(103.2)	
	(4.40) 22.11	(0.35) 13.80	(4.05) 25.27	(3.20) 30.09	(2.22) 43.60	(0.30) 22.40	(2.20) 44.22	(2.50) 36.40	(0.30) 22.40	(2.35) 38.70	(0.30) 22.40	(2.50) 36.40	(0.35) 19.20		Time over District Average Speed per Hour	

VENTURA SUBDIVISION

WESTWARD

Supplement No. 1 to Time Table No. 183 April 14, 1946		Distance from Los Angeles	FIRST CLASS										SECOND CLASS	THIRD CLASS	
			71	99	51	97	25	373	69	59	55	75	447	831	833
			Passenger	Morning Daylight	San Joaquin	Noon Daylight	Owl	C. M. W.	Coaster	West Coast	Tehachapi	Lark	Freight	Freight	Freight
STATIONS			Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily Ex. Sat., Sun.	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily Ex. Sunday	Arrive Daily	Arrive Daily
TO-R SANTA BARBARA W. 1.2	D.T.	103.2	s 10.15 AM	s 10.30 AM		s 2.28 PM		10.25 PM	s 10.45 PM			s 11.37 PM		3.37 AM	12.45 PM
EAST SANTA BARBARA W. 5.6		102.0	10.07	10.25		2.24		10.17	10.37			**11.32**		3.30	12.39
ORTEGA W. 4.0		96.6	9.58	10.17		2.16		10.09	10.31			11.24		3.20	12.29
TO CARPINTERIA W. 2.1		92.7	s 9.50	10.12		2.11		10.03	10.25			11.18		3.06	12.21
WAVE W. 2.3		90.5	9.42						10.20					2.58	12.13
PUNTA W. 3.7		88.2	9.38	10.06		2.05		9.56	10.16			11.12		2.54	12.09
SEACLIFF W. 3.4		85.3	9.33	10.02		2.01		9.52	10.11			11.08		2.49	12.04 PM
DULAH W. 4.3		81.0	9.27	9.57		1.56			10.06			11.03		2.42	11.57 AM
VENTURA JCT. W. 1.9		76.6													
TO VENTURA W. 3.9		75.7	s 9.18	9.50		1.49		9.40	s 9.58			10.55		2.32	11.47
MONTALVO W. 5.7		70.7	f 9.04						9.50			10.47		2.24	11.39
TO OXNARD W. 3.7		66.1	s **8.58**	9.39		1.37		9.27	s 9.44			10.41		2.15	11.30
LEESDALE W. 4.8		61.8	8.44	9.35		1.33		**9.22**	9.34			10.36		2.01	11.15
TO CAMARILLO W. 2.8		57.3	f 8.39	**9.31**		1.29		9.17	**9.30**			10.31		1.54	11.08
SOMIS W. 3.3		54.1	f 8.33			1.26			9.25			10.27		1.49	11.03
LAGOL W. 4.2		51.0	8.28	9.25		1.23			9.21			10.23		1.44	10.58
TO MOORPARK W. 4.9		46.8	f 8.23	9.21		1.19		9.07	9.16			10.18		**1.37**	10.51
STRATHEARN W. 5.3		41.7	8.15	9.16		1.14			9.10			10.12		1.29	10.43
TO SANTA SUSANA W. 3.4	Automatic Block System	36.4	f 8.08	9.11		1.09		**8.55**	9.05			**10.05**		1.21	**10.35**
HASSON W. 5.0		32.9	f **8.02**			1.05			**8.59**			10.00		1.15	10.15
TO CHATSWORTH W. 4.2		28.4	f 7.43	9.01		12.58		8.35	8.48			9.51		1.04	10.04
TO NORTHRIDGE W. 4.1		24.0	f **7.35**	8.57		12.54		8.30	8.43			9.46		12.57	9.57
RAYMER W. 4.7		19.8	7.24	8.53		12.50		8.25	8.37			9.41		12.49	9.49
HEWITT W. 3.5		15.5	**7.18**	8.49		12.46		8.20	8.31			9.35		12.40	9.40
TO BURBANK JCT. W. 0.7	Double Track	11.2	7.03	8.43	8.57 AM	12.41	5.59 PM	8.15	8.25	8.43 PM	9.10 PM	9.30	7.50 PM	12.30	9.30
BURBANK W. 5.0		10.7	f 7.02								f 9.05				
GLENDALE W. 0.2		5.7	s 6.50	s 8.35	s 8.48	s 12.33	s 5.50		s 8.15	s 8.33	s 8.57	s 9.22			
GLENDALE TOWER P. E. Ry. CROSSING W. 1.2		5.5													
ARROYO JCT. W. 1.2		4.3													
TO-R LOS ANGELES YARD W. 0.9		3.1						8.00 PM			f		7.20 PM	12.01 AM	9.00 AM
DAYTON AVE. TOWER W. 0.9		2.2	6.40	8.25	8.40	12.25	5.40		8.05	8.21	8.47	9.11			
GLENDALE JCT. W. 0.4		1.3													
EAST BANK JCT. W. 0.15		0.9	6.36	8.21	8.36	12.21	5.36		8.01	8.16	8.42	9.06			
U. P. R. R. CROSSING W. 0.13		0.75													
A. T. & S. F. Ry. CROSSING MISSION TOWER W. 0.62		0.62	6.34	**8.19**	8.34	12.19	5.34		7.59	8.14	8.36	9.04			
TO-R LOS ANGELES LAUPT		0.0	6.30 AM	**8.15 AM**	8.30 AM	12.15 PM	5.30 PM		7.55 PM	8.10 PM	8.30 PM	9.00 PM			
(103.2)			Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily Ex. Sat., Sun.	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily Ex. Sunday	Leave Daily	Leave Daily
Time over District Average Speed per Hour			(3.45) 27.56	**(2.15) 45.86**	(0.27) 24.80	(2.13) 46.55	(0.29) 23.10	(2.25) 42.70	(2.50) 36.40	(0.33) 20.36	(0.40) 16.79	**(2.37) 39.43**	(0.30) 16.20	(3.36) 28.66	(3.45) 27.52

RULES 86 and 93. Between Santa Barbara and Burbank Jct., Second and inferior class trains, extra trains and engines, except trains handling passenger equipment only, must clear the time of Nos. 96, 97, 98 and 99 not less than 10 minutes, and must be clear of main track and insulated joints at meeting and passing points for Nos. 96, 97, 98 and 99.

RULE 5. Schedule time and train orders at Burbank Jct. apply at end of double track.

Maximum speed provided for passenger trains, other than streamlined trains, will apply to Nos. 373 and 374 when those trains consist entirely of passenger equipment, or cars with steel wheels, including box cars with steel wheels, or caboose with steel wheels, except that maximum speed of 60 MPH must not be exceeded.

Between Mission Tower and Dayton Ave. Tower, via East Bank Jct., trains or engines may use main tracks, in either direction, being governed by signal indication.

Trains or engines stopped by interlocking signals at signal bridges 3, 4, or 6, will, if signal does not clear, call signal operator on telephone located on signal bridge.

Rules and regulations of Los Angeles Union Passenger Terminal must be observed between terminal limits and end of tracks at Los Angeles.

Westward freight trains approaching Tunnel 26 at less than 12 MPH must stop and double to Hasson.

Revenue passenger trains except exclusively Government business must stop at Glendale.

Additional flag stops—No. 71, Simi (MP 433.5) Summerland (MP 376.2).

Additional flag stops to receive or discharge passengers:

No. 71 Los Angeles Yard, receive DH trainmen and enginemen.

No. 25 Burbank, receive to Mojave or beyond.

No. 75 Ventura, receive to Salinas or beyond.

No. 51, reduce speed at Burbank to dispatch U. S. Mail.

No. 25, reduce speed at Burbank to receive mail.

Dulah Siding will not hold more than 15 passenger cars and one engine.

ADDITIONAL STATIONS		
NAME	Mile Post	Capacity
Santa Barbara—Los Angeles		
Summerland . . . . (Spur)	376.2	20
Lemon . . . . "	400.2	15
El Rio	405.6	12
Simi . . . . (Spur)	433.5	20
Vega	460.5	. . . . .
Sepulveda . . . . (Spur)	474.3	10
West Glendale . . "	475.0	12
Industrial . . . . . . "	477.9	22
Taylor	479.3	. . . . .

VENTURA SUBDIVISION

WESTWARD

Time Table No. 183

July 8, 1945

STATIONS	Distance from Los Angeles	FIRST CLASS									THIRD CLASS					
		339	51	99	71	25	59	69	55	75	831	801	803	833	805	807
			San Joaquin	Daylight	Passenger	Owl	West Coast	Coaster	Tehachapi	Lark	Freight	Freight	Freight	Freight	Freight	Freight
		Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily
TO-R **SANTA BARBARA** D.T. W. 1.2	103.2			s 10.30 AM	s 4.50 PM			s 9.40 PM		s 11.37 PM	3.37 AM			12.45 PM		
EAST SANTA BARBARA D.T. W. 5.6	102.0			10.26	4.45			9.34		**11.32**	3.30			12.39		
ORTEGA W. 4.0	96.6			10.19	4.35			9.26		11.24	3.20			12.29		
TO **CARPINTERIA** W. 2.1	92.7			10.14	s 4.29			9.20		11.18	**3.06**			12.21		
WAVE W. 2.3	90.5				4.18			9.15			2.58			12.13		
PUNTA W. 3.7	88.2			10.08	4.12			9.10		11.12	2.54			12.09		
SEACLIFF W. 3.4	85.3			10.04	**4.05**			9.05		11.08	2.49			12.04 PM		
DULAH W. 4.3	81.0			9.59	3.49			8.59		11.03	2.42			11.57 AM		
VENTURA JCT. W. 1.9	76.6															
TO **VENTURA** W. 3.9	75.7			9.52	s 3.40			s 8.50		10.55	2.32			11.47		
MONTALVO W. 5.7	70.7				f 3.22			8.32		10.49	2.24			11.39		
TO **OXNARD** W. 3.7	66.1			9.41	s 3.15			s 8.25		10.43	2.15			11.30		
LEESDALE W. 4.8	61.8			9.37	2.53			8.10		10.37	2.01			11.15		
TO **CAMARILLO** W. 2.8	57.3			**9.32**	f 2.47			8.05		10.31	1.54			11.08		
SOMIS W. 3.3	54.1				f 2.39			8.01		10.27	1.49			11.03		
LAGOL W. 4.2	51.0			9.26	2.34			7.57		10.23	1.44			10.58		
TO **MOORPARK** W. 4.9	46.8			9.22	f 2.28			7.52		10.18	**1.37**			10.51		
STRATHEARN W. 5.3	41.7			9.17	2.20			7.46		10.12	1.29			10.43		
TO **SANTA SUSANA** W. 3.4	36.4			9.11	f 2.13			7.40		10.05	1.21			**10.35**		
HASSON W. 5.0	32.9			9.07	f 2.07			7.36		10.00	1.15			10.15		
TO **CHATSWORTH** W. 4.2	28.4			9.00	f 1.59			7.27		9.51	1.04			10.04		
TO **NORTHRIDGE** W. 4.1	24.0			8.56	f 1.49			7.21		9.46	12.57			9.57		
RAYMER W. 4.7	19.8			8.52	1.42			7.15		9.41	12.49			9.49		
HEWITT W. 3.5	15.5			8.48	1.36			7.09		9.35	12.40			9.40		
TO **BURBANK JCT.** W. 0.7	11.2	3.30 AM	8.29 AM	8.43	1.30	5.31 PM	6.01 PM	7.03	9.12 PM	9.30	12.30	12.35 AM	8.55 AM	9.30	9.45 AM	6.10 PM
BURBANK W. 5.0	10.7				f 1.29				f 9.06							
GLENDALE W. 0.2	5.7	3.22	s 8.21	s 8.35	s 1.20	s 5.23	s 5.53	s 6.54	s 8.57	s 9.22						
GLENDALE TOWER P. E. Ry. CROSSING W. 1.2	5.5															
ARROYO JCT. W. 1.2	4.3															
TO-R **LOS ANGELES YARD** W. 0.9	3.1								f		12.01 AM	12.10 AM	8.30 AM	9.00 AM	9.20 AM	5.45 PM
DAYTON AVE. TOWER W. 0.9	2.2	3.11	8.11	8.25	1.11	5.11	5.41	6.41	8.36	9.11						
GLENDALE JCT. W. 0.4	1.3															
EAST BANK JCT. W. 0.15	0.9	3.06	8.06	8.21	1.06	5.06	5.36	6.36	8.31	9.06						
U. P. R. R. CROSSING W. 0.13	0.75															
A. T. & S. F. Ry. CROSSING **MISSION TOWER** W. 0.62	0.62	3.04	8.04	8.19	1.04	5.04	5.34	6.34	8.29	9.04						
TO-R **LOS ANGELES** LAUPT	0.0	3.00 AM	8.00 AM	8.15 AM	1.00 PM	5.00 PM	5.30 PM	6.30 PM	8.25 PM	9.00 PM						
(103.2)		Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily
Time over District Average Speed per Hour		(0.30) 22.40	(0.29) 23.17	(2.15) 45.86	(3.50) 26.92	(0.31) 21.67	(0.31) 21.67	(3.10) 32.58	(0.47) 14.29	(2.37) 39.43	(3.36) 28.66	(0.25) 19.44	(0.25) 19.44	(3.45) 27.52	(0.25) 19.44	(0.25) 19.44

Automatic Block System

Double Track

RULES 86 and 93. Between Santa Barbara and Burbank Jct., Second and inferior class trains, extra trains and engines, except trains handling passenger equipment only, must clear the time of Nos. 98 and 99 not less than 10 minutes, and must be clear of main track and insulated joints at meeting and passing points for Nos. 98 and 99.

RULE 5. Schedule time and train orders at Burbank Jct. apply at end of double track.

Between Mission Tower and Dayton Ave. Tower, via East Bank Jct., trains or engines may use main tracks, in either direction, being governed by signal indication.

Trains or engines stopped by interlocking signals at signal bridges 3, 4, or 6, will, if signal does not clear, call signal operator on telephone located on signal bridge.

Rules and regulations of Los Angeles Union Passenger Terminal must be observed between terminal limits and end of tracks at Los Angeles.

Westward freight trains approaching Tunnel 26 at less than 12 MPH must stop and double to Hasson.

Revenue passenger trains except exclusively Government business must stop at Glendale.

Additional flag stops—No. 71, Simi (MP 433.5) Summerland (MP 376.2).

Additional flag stops to receive or discharge passengers:

No. 71 Los Angeles Yard, receive DH trainmen and enginemen.

No. 25 Burbank, receive to Mojave or beyond.

No. 75 Ventura, receive to Salinas or beyond.

No. 51, reduce speed at Burbank to dispatch U. S. Mail.

No. 25, reduce speed at Burbank to receive mail.

Dulah Siding will not hold more than 15 passenger cars and one engine.

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Santa Barbara—Los Angeles		
Summerland . . . . (Spur)	376.2	20
Lemon . . . . "	400.2	15
El Rio	405.6	12
Simi . . . . (Spur)	433.5	20
Vega	460.5	. . . . . .
Sepulveda . . . . (Spur)	474.3	10
West Glendale . . "	475.0	12
Industrial . . . . . "	477.9	22
Taylor	479.3	. . . . . .

POMONA SUBDIVISION

EASTWARD

Capacity of Sidings in Car Lengths		SECOND CLASS					FIRST CLASS					Distance from San Francisco		Time Table No. 183 July 8, 1945 STATIONS
		830 Freight Leave Daily	828 Freight Leave Daily	826 Freight Leave Daily	824 Freight Leave Daily	822 Freight Leave Daily	6 Argonaut Leave Daily	4 Golden State Limited Leave Daily	370 Leave Daily	44 Californian Leave Daily	2 Sunset Limited Leave Daily			
Los Angeles yard	BKW OYP	11.30PM	9.45PM	2.50PM	7.00AM	1.30AM						479.7		TO-R **LOS ANGELES YARD** 0.9
	I											480.6		**DAYTON AVE. TOWER** 0.9
												481.5		**GLENDALE JCT.** 0.4
												481.9		**EAST BANK JCT.** 0.2
												482.1		**TAYLOR JCT.**
	BKW IYP						6.45PM	6.30PM	5.25PM	5.10PM	8.30AM	481.9		TO-R **LOS ANGELES** LAUPT 0.62
	I						6.49	6.34	5.29	5.14	8.34	482.52		**MISSION TOWER** A. T. & S. F. Ry. CROSSING 0.13
												482.65		U. P. R. R. CROSSING 0.15
							6.50	6.35	5.30	5.15	8.35	482.8		**TAYLOR JCT.** 4.9
	P	12.01AM	10.15	3.20	7.30	2.00	s 7.05	s 6.50	5.45	s 5.30	s **8.55**	487.7		TO **ALHAMBRA** E. 2.1
83	P	12.07	10.21	3.26	7.36	2.06	**7.11**	6.56	5.50	5.35	8.58	490.6		**SAN GABRIEL** E. 3.2
140	P	12.15	10.29	3.34	7.44	2.14	7.17	**7.06**	5.57	5.42	9.03	494.6		**EL MONTE** E. 0.4
	I											495.0	Automatic Block System	**EL MONTE TOWER** P. E. Ry. CROSSING E. 3.2
125	WP	12.20	10.34	3.39	7.49	2.19	7.22	7.11	6.02	5.47	**9.10**	497.3		TO **BASSETT** E. 2.9
75	P	12.26	10.40	3.45	7.55	2.25	7.27	7.15	6.07	5.52	9.15	500.7		TO **PUENTE** E. 3.1
66	P	12.34	10.47	3.52	8.03	**2.35**	7.32	7.20	**6.11**	**5.56**	9.20	503.5		**MARNE** E. 3.4
122	P	12.42	10.55	4.00	8.12	2.50	7.37	7.25	6.16	6.01	9.25	506.8		TO **WALNUT** E. 3.7
67	P	1.03	11.05	4.10	**8.23**	3.05	7.43	7.31	6.22	6.07	**9.31**	510.7		**SPADRA** E. 2.2
Yard Limits 299	BKWTP	1.30	11.19	4.22	**8.45**	3.21	s 7.54	s 7.38	f **6.36**	s 6.15	s 9.41	514.3		TO **POMONA** E. 4.5
128	P	1.45	11.29	4.41	**9.05**	3.32	8.01	7.43	6.42	**6.30**	9.46	517.8		**NAROD** E. 2.7
Yard Limits 117	P	**1.55**	11.39	4.50	9.15	3.45	8.10	s 7.48	6.46	6.35	s 9.52	520.2		TO **ONTARIO** E. 3.8
65	WP	2.03	11.47	**5.00**	9.24	3.55	8.16	7.53	6.50	6.39	9.56	523.8		**GUASTI** E. 3.9
75	P	2.12	11.56PM	5.07	9.30	4.03	8.21	7.58	6.54	6.43	10.00	527.5		**KAISER** E. 2.3
125	YP	2.17	12.01AM	5.12	9.35	4.09	8.25	8.02	6.57	6.46	10.03	529.7		TO **SOUTH FONTANA** E. 2.2
65	P	2.27	12.11	5.22	9.40	4.19						532.1		**AILSA** E. 1.6
111	P	2.36	12.25	5.31	9.45	4.28	8.31	8.09	7.01	6.50	**10.10**	534.7		TO **BLOOMINGTON** E. 4.9
	I											538.7		**COLTON TOWER** A. T. & S. F. Ry. CROSSING U. P. R. R. CROSSING E. 0.3
Colton yard	BKWOTYP	2.50AM	**12.45AM**	5.50PM	**10.00AM**	4.45AM	s 8.40PM	s 8.20PM	s 7.10PM	s 7.00PM	s 10.20AM	539.0		TO-R **COLTON**
		Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily			(58.6)
		(3.20) 17.55	(3.00) 19.53	(3.00) 19.53	(3.00) 19.53	(3.15) 18.30	(1.55) 29.79	(1.50) 31.14	(1.45) 32.62	(1.50) 31.14	(1.50) 31.14			Time over District Average Speed per Hour

Time Table No. 183

July 8, 1945

Pasadena Branch

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco		STATIONS	Westward Distance from Pasadena
L. A. Yard P	487.7	TO	**ALHAMBRA** 0.8	4.8
	488.5		P. E. Ry. CROSSING (Stop) 1.0	4.0
I	489.5		P. E. Ry. CROSSING 1.7	3.0
	491.2		**RAYMOND HOTEL** A. T. & S. F. Ry. CROSSING 1.3	1.3
P	492.5		**PASADENA**	0.0
			(4.8)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
North Shorb..........	488.5	......
South Pasadena.......	489.9	......
Garfield Ave.....(Spur)	490.6	8

Time Table No. 183

July 8, 1945

Covina Branch

Capacity of Sidings in Car Lengths		Eastward Distance from San Francisco		STATIONS		Westward Distance from Pomona
125	WP	497.3	TO	**BASSETT** 3.6		17.8
		500.9		**BALDWIN PARK** P. E. Ry. CROSSING (Stop) 4.2	Staff System	14.2
Yard Limits	WP	505.1		**COVINA** 2.3		10.0
22		507.4		**CHARTER OAK** 1.1		7.7
		508.5		**LONE HILL** P. E. RY. CROSSING 1.0		6.6
32		509.5		**SAN DIMAS** 2.4		5.6
28		511.9		**LA VERNE** 1.4		3.2
		513.3		**GANESHA JCT.** 1.8		1.8
Yard Limits 299	BKWTP	515.1	TO	**POMONA**		0.0
				(17.8)		

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Crushton............	501.4	......
Irwindale...........	502.3	30
Lateen.........(Spur)	503.0	8
Azusa Ave...........	504.1	......
Savoy...............	506.7	......
Hobbs..........(Spur)	512.9	6

Rules and regulations of Los Angeles Union Passenger Terminal must be observed between Terminal limits and end of tracks at Los Angeles.

Between Mission Tower and Dayton Ave. Tower, via East Bank Jct., trains or engines may use main tracks, in either direction, being governed by signal indication.

Trains or engines stopped by interlocking signals at signal bridges 3, 4, or 6, will, if signal does not clear, call signal operator on telephone located on signal bridge.

RULE 5. Schedule time and train orders apply as follows:

Eastward trains at Alhambra, at end of double track.

First-class trains at Pomona, at passenger siding.

First-class trains at Colton, at station sign.

ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS

Train	At	Receive or Discharge	To (or Beyond)	From (or Beyond)	Frequency
6	El Monte, Ontario	Receive	Yuma		Daily
44	El Monte, Ontario	Receive Revenue	East of Wellton		Daily

POMONA SUBDIVISION

WESTWARD

Time Table No. 183

July 8, 1945

STATIONS	Distances from Colton	FIRST CLASS 3 Golden State Limited Arrive Daily	 5 Argonaut Arrive Daily	 43 Californian Arrive Daily	 371 Arrive Daily	 1 Sunset Limited Arrive Daily	THIRD CLASS 821 Freight Arrive Daily	 823 Freight Arrive Daily	 825 Freight Arrive Daily
TO-R **LOS ANGELES YARD** 0.9	58.6						3.50AM	10.50AM	7.15PM
DAYTON AVE. TOWER 0.9	57.7								
GLENDALE JCT. 0.4	56.8								
EAST BANK JCT. 0.2	56.4								
TAYLOR JCT.	56.2								
TO-R **LOS ANGELES** LAUPT 0.62	57.1	s 9.25AM	s 9.40AM	s 11.55AM	s 1.30PM	s 7.45PM			
MISSION TOWER A. T. & S. F. Ry. CROSSING 0.13	56.48								
U. P. R. R. CROSSING 0.15	56.35								
TAYLOR JCT. 4.9	56.2								
TO **ALHAMBRA** W. 2.7	51.3	s **8.55**	s 9.25	s 11.34	1.05	s 7.20	3.21	10.20	6.45
SAN GABRIEL W. 3.9	48.4	8.51	9.20	11.25	12.55	**7.11**	3.15	10.14	6.39
EL MONTE W. 0.4	44.4	8.47	9.15	11.19	12.49	**7.06**	3.06	10.05	6.30
EL MONTE TOWER P. E. Ry. CROSSING W. 3.0	44.0								
TO **BASSETT** W. 2.4	41.7	8.42	**9.10**	11.13	12.44	7.01	2.58	9.58	6.24
TO **PUENTE** W. 3.0	38.3	8.37	9.05	11.08	12.39	6.56	2.51	9.51	6.19
MARNE W. 4.0	35.5	8.33	9.00	11.04	12.34	6.52	**2.35**	9.45	**6.11** 5.45
TO **WALNUT** W. 3.2	32.2	8.28	8.55	10.59	12.29	6.48	2.24	9.39	5.37
SPADRA W. 4.3	28.3	**8.23**	8.50	10.53	12.23	6.43	2.17	**9.31**	5.30
TO **POMONA** W. 3.0	24.7	s 8.18	**8.45**	f 10.47	f 12.17	s **6.36**	2.09	9.12	5.22
NAROD W. 2.7	21.2	8.12	8.37	10.38	12.10	**6.30**	2.02	**9.05**	5.15
TO **ONTARIO** W. 3.3	18.8	s 8.07	s 8.32	f 10.33	12.04PM	s 6.26	**1.55**	8.59	5.08
GUASTI W. 4.2	15.2	8.01	8.26	10.26	11.58AM	6.18	1.34	8.53	**5.00**
KAISER W. 2.2	11.5	7.56	8.21	10.21	11.52	6.13	1.25	8.47	4.50
TO **SOUTH FONTANA** W. 2.0	9.3	7.53	8.18	10.17	11.47	6.09	1.20	8.42	4.40
AILSA W. 2.0	6.9						1.15	8.36	4.35
TO **BLOOMINGTON** W. 4.9	4.3	7.47	8.12	**10.10**	11.41	6.04	1.05	8.30	4.30
COLTON TOWER A. T. & S. F. Ry. CROSSING U. P. R. R. CROSSING W. 0.3	0.3								
TO-R **COLTON**	0.0	7.38AM	8.02AM	**10.00AM**	11.30AM	5.55PM	**12.45AM**	8.10AM	4.10PM
(58.6)		Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily
Time over District Average Speed per Hour		(1.47) 32.01	(1.38) 34.95	(1.55) 29.79	(2.00) 28.50	(1.50) 31.14	(3.05) 19.50	(2.40) 21.09	(3.05) 19.00

Double Track

Automatic Block System

No. 3 stop on flag Puente to receive U. S. registered mail.

Rules and regulations of Los Angeles Union Passenger Terminal must be observed between Terminal limits and end of tracks at Los Angeles.

Between Mission Tower and Dayton Ave. Tower, via East Bank Jct., trains or engines may use main tracks, in either direction, being governed by signal indication.

Trains or engines stopped by interlocking signals at signal bridges 3, 4, or 6, will, if signal does not clear, call signal operator on telephone located on signal bridge.

RULE 5. Schedule time and train orders apply as follows:

Eastward trains at Alhambra, at end of double track.

First-class trains at Pomona, at passenger siding.

First-class trains at Colton, at station sign.

Time Table No. 183

July 8, 1945

Chino Branch

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco	STATIONS	Westward Distance from End of Track
Yard Limits 299 BKWTP	514.3	TO **POMONA** 1.1	5.7
I	515.4	**POMONA JCT. TOWER** U. P. R. R. CROSSING 4.6	4.6
	520.0	**CHINO**	0.0
		(5.7)	

Time Table No. 183

July 8, 1945

Riverside Branch

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco		STATIONS	Westward Distance from Riverside
Colton Yard BKWOTYP	539.0	See Note	TO **COLTON** 5.0	7.2
I	544.0		A. T. & S. F. Ry. CROSSING 1.4	2.2
	545.4		**RIVERSIDE JCT.** 0.8	0.8
Yd. Limits P	546.2		**RIVERSIDE**	0.0
			(7.2)	

Track between M.P. 540.085 and M.P. 545.914 also used by P. E. Ry. trains.

See Special Instructions under Special Signals.

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Los Angeles—Colton		
Aurant................	484.6	91
Stoneman........(Spur)	489.3	14
Rudell.......... "	491.7	9
Racimo .... "	522.4	14
Riverside Branch		
Grand Terrace........	541.2	2
Highgrove............	542.3	.....
Orange Center.........	543.3	.....
Point of Rocks........	543.8	.....
Iowa Ave.............	544.2	5
Chicago Ave..........	544.8	.....

ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS

Train	At	Receive or Discharge	To (or Beyond)	From (or Beyond)	Frequency
5	Pomona, El Monte	Discharge		Yuma	Daily
43	El Monte	Discharge Revenue		E. of El Paso	Daily
3	El Monte	Discharge		El Paso	Daily

BEAUMONT SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco	Time Table No. 183 July 8, 1945 Redlands Branch STATIONS	Westward Distance from Crafton
P	544.5	BRYN MAWR 3.3	6.9
Yd. Limits W	547.8	REDLANDS, 2nd STREET 3.6	3.6
Yard Limits	551.4	CRAFTON	0.0
		(6.9)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Motor Jct.	545.0	......
Warner (Spur)	549.9	2
Mentone	550.5	......

VENTURA SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco		Time Table No. 183 July 8, 1945 Santa Paula Branch STATIONS	Westward Distance from Saugus
Yard Limits 40 YP	403.2		MONTALVO 4.4	45.5
56 P	407.6	TO	SATICOY 7.1	41.1
Yard Limits 44 WP	414.7	TO	SANTA PAULA 9.8	34.0
Yard Limits 36 BKP	424.5	TO-R	FILLMORE 3.7	24.2
32 P	428.2		CAVIN 3.6	20.5
WP	431.8		PIRU 12.3	16.9
33 P	444.1		NEWHALL RANCH 4.6	4.6
E103 Yd. Lmts. W 93 WOIYP	448.7	TO-R	SAUGUS	0.0
			(45.5)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Kimball (Spur)	404.5	15
Limco	411.0	......
Haines	411.3	......
Briggs	413.3	17
Kevet (Spur)	415.9	8
Keith	421.2	22
Sespe	421.8	......
Buckhorn	429.9	......
Camulos	434.3	......

VENTURA SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco	Time Table No. 183 July 8, 1945 Ojai Branch STATIONS	Westward Distance from Ojai
Ventura Yd. Limits P	397.3	VENTURA JCT. 15.0	15.0
W	412.3	OJAI	0.0
		(15.0)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Chrisman (Spur)	399.0	12
Wadstrom "	400.3	19
Ortonville	400.8	......
Weldons (Spur)	402.4	3

BEAUMONT SUBDIVISION

Capacity of Sidings in Car Lengths	EASTWARD FIRST CLASS 6 Argonaut Leave Daily	4 Golden State Limited Leave Daily	370 Leave Daily	44 Californian Leave Daily	2 Sunset Limited Leave Daily	Distance from San Francisco	Time Table No. 183 July 8, 1945 STATIONS	Distance from Indio Yard	WESTWARD FIRST CLASS 3 Golden State Limited Arrive Daily	5 Argonaut Arrive Daily	43 Californian Arrive Daily	371 Arrive Daily	1 Sunset Limited Arrive Daily
Colton yard BKWOTYP	8.55 PM	8.35 PM	7.20 PM	7.12 PM	10.38 AM	539.0	TO-R COLTON P. E. Ry. CROSSING E. 1.3 — W. 2.9	72.3	s 7.28 AM	s 7.52 AM	s 9.47 AM	s 11.10 AM	s 5.45 PM
258 P						542.6	LOMA LINDA E. 3.9 — W. 1.9	68.7					
P						544.5	BRYN MAWR E. 1.5 — W. 2.1	66.8					
120 P	9.07	8.49		7.26	10.51	546.3	REDLANDS E. 2.8 — W. 2.9	65.0	7.11	7.36	f 9.28		5.24
126 P						549.1	ORDWAY E. 3.9 — W. 3.8	62.2					
115 WP						552.7	EL CASCO E. 4.7 — W. 4.7	58.6					
122 P						557.2	HINDA E. 2.3 — W. 2.2	54.1					
119 P						559.7	NICKLIN E. 1.8 — W. 3.1	51.6					
245 WKOYP	f 9.45	9.25	f 8.08	8.01	s 11.25	562.0	BEAUMONT E. 4.2 — W. 3.2	49.3	6.41	7.06	f 8.57	f 10.16	4.53
130 P						565.5	PERSHING E. 2.6 — W. 2.4	45.8					
110 P	f 9.57	9.37	f 8.24	8.14	s 11.40 AM	568.2	BANNING E. 3.5 — W. 3.6	43.1	6.26	6.50	f 8.39	f 9.59	4.36
120 P						571.5	OWL E. 1.9 — W. 2.0	39.8					
123 127 WP						574.1	CABAZON E. 2.2 — W. 2.2	37.2					
120 P						576.2	MONS E. 2.2 — W. 2.2	35.1					
118 P						578.6	FINGAL E. 4.0 — W. 3.9	32.7					
108 WP	f 10.31	s 10.08	f 8.54	s 8.44	s 12.11 PM	582.6	PALM SPRINGS E. 3.4 — W. 3.6	28.7	s 5.49	6.14	f 8.03	f 9.24	s 4.01
118 P						585.4	HUGO E. 2.9 — W. 2.8	25.9					
65 109 WYP						588.1	GARNET E. 2.7 — W. 2.9	23.2					
120 P						591.6	SALVIA E. 4.3 — W. 4.3	19.7					
121 P						595.1	RIMLON E. 3.7 — W. 3.5	16.2					
108 P						599.0	EDOM E. 2.9 — W. 3.0	12.3					
120 P						601.5	DRY CAMP E. 4.9 — W. 5.0	9.8					
129 P						606.5	MYOMA E. 4.6 — W. 3.3	4.8					
Indio Yd.	s 11.14 PM	s 10.50 PM	s 9.35 PM	s 9.25 PM	s 12.55 PM	610.9	TO-R INDIO 0.4	0.4	4.50 AM	5.20 AM	7.10 AM	8.35 AM	3.10 PM
BKWOYP						611.3	TO-R INDIO YARD	0.0					
	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily		(72.3)		Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily
	(2.19) 31.03	(2.15) 31.95	(2.15) 31.95	(2.13) 32.43	(2.17) 31.48		Time over District Average Speed per Hour		(2.38) 27.40	(2.32) 28.31	(2.37) 27.47	(2.35) 27.85	(2.35) 27.85

Automatic Block System

Centralized Traffic Control

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Haig (Spur)	555.7	19

See Pages 8 and 9 for additional schedules between Indio and Indio Yard.

Nos. 1, 3 and 4 passing Beaumont and Banning and No. 3 passing Palm Springs, reduce speed sufficiently to permit throwing U. S. Mail in mail car.

No. 43 reduce speed at Edom and Cabazon, stopping when necessary to exchange parcel post.

Rule 5. Schedule time and train orders for first-class trains at Colton and Indio apply at station signs.

ADDITIONAL FLAG STOPS TO RECEIVE OR DISCHARGE PASSENGERS

Train	At	Receive or Discharge	To (or Beyond)	From (or Beyond)	Frequency
2	Redlands	Receive, Discharge Revenue	Niland	Alhambra	Daily
44	Redlands, Beaumont, Banning	Receive Revenue	East of Wellton		Daily
44	Beaumont, Banning	Discharge Military Personnel			Daily
4	Redlands, Beaumont, Banning	Receive	East of El Paso		Daily
6	Redlands	Receive, Discharge	Yuma	Alhambra	Daily
3	Banning, Beaumont, Redlands	Discharge		El Paso	Daily
5	Palm Springs, Banning, Beaumont, Redlands	Discharge		Yuma	Daily
1	Banning, Beaumont, Redlands	Receive, Discharge Revenue	Alhambra	Imperial Valley Points	Daily

FIRESTONE PARK SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓		Time Table No. 183 July 8, 1945 Santa Ana Branch STATIONS	Westward Distance from Dyer ↑
L. A. Yard WYP	489.1	TO-R	**FIRESTONE PARK**	30.3
			3.0	
I	492.1		U. P. R. R. CROSSING **SOUTHGATE (Atlantic Blvd.)**	27.3
			2.9	
	495.0	TO	**DOWNEY**	24.4
			9.4	
67	504.4		**BUENA PARK**	15.0
			4.6	
Yard Limits WYP	509.0		**WEST ANAHEIM**	10.4
			1.2	
	510.2	TO	**ANAHEIM**	9.2
			1.7	
P	511.9		**TUSTIN JCT.**	7.5
			5.1	
Yard Limits BKWOYP	517.0	TO-R	**SANTA ANA**	2.4
			2.4	
	519.4		**DYER**	0.0
			(30.3)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Ardmore........(Spur)	490.1	9
Norwalk..........	499.1	......
Main St..........	515.6	......

FIRESTONE PARK SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓	Time Table No. 183 July 8, 1945 Tustin Branch STATIONS	Westward Distance from Tustin ↑
	511.9	**TUSTIN JCT.**	10.5
		0.5	
I	512.4	**ANAHEIM TOWER** **A. T. & S. F. Ry. CROSSING**	10.0
		2.1	
	514.5	**MARLBORO** **A. T. & S. F. Ry. CROSSING (Stop)**	7.9
		7.9	
	522.4	**TUSTIN**	0.0
		(10.5)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Villa Park..........	516.7	......
El Modena..........	519.4	......

FIRESTONE PARK SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓	Time Table No. 183 July 8, 1945 Los Alamitos Branch STATIONS	Westward Distance from Los Alamitos ↑
Yard Limits WYP	509.0	**WEST ANAHEIM**	9.4
		4.6	
	513.6	**STANTON**	4.8
		0.5	
Y	514.1	**P. E. Ry. CROSSING (Stop)** **STANTON JCT.**	4.3
		4.3	
	518.4	**LOS ALAMITOS**	0.0
		(9.4)	

FIRESTONE PARK SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓	Time Table No. 183 July 8, 1945 Smeltzer Branch STATIONS	Westward Distance from End of Track ↑
Y	514.1	**STANTON JCT.**	6.4
		6.4	
	520.5	**WINTERSBURG**	0.0
		(6.4)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Westminster..........	517.4	......
Smeltzer..........	519.5	......

FIRESTONE PARK SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓		Time Table No. 183 July 8, 1945 Long Beach Branch STATIONS	Westward Distance from Long Beach ↑
YP	501.4		**WILMINGTON (Anaheim Blvd.)**	2.1
			0.4	
I	501.8		**A. T. & S. F. Ry. CROSSING**	1.7
			0.2	
I	502.0		**U. P. R. R. CROSSING**	1.5
			0.4	
	502.4		**P. E. Ry. CROSSING (Stop)**	1.1
			1.1	
	503.5	TO	**LONG BEACH**	0.0
			(2.1)	

CALEXICO SUBDIVISION

Capacity of Sidings in Car Lengths	EASTWARD SECOND CLASS 452 S.D.&A.E. Mixed Leave Daily Ex. Monday	EASTWARD FIRST CLASS 362 San Diego Passenger Leave Daily	Distance from San Francisco			Time Table No. 183 July 8, 1945 STATIONS	Distance from Calexico	WESTWARD FIRST CLASS 363 San Diego Passenger Arrive Daily	WESTWARD SECOND CLASS 451 S.D.&A.E. Mixed Arrive Daily Ex.Saturday
Yard Limits 148 BKWOYP			667.5	Automatic Block System	TO-R	**NILAND**	41.0		
						E. 7.5 — W. 8.5			
Yard Limits 90 YP			675.7		TO-R	**CALIPATRIA**	32.8		
						E. 9.4 — W. 10.8			
Yard Limits BKWP			686.2		TO-R	**BRAWLEY**	22.3		
						E. 10.2 — W. 9.2			
Yd. Limits P 131			695.6		TO	**IMPERIAL**	12.9		
						E. 3.4 — W. 3.8			
Yard Limits 87 BKWYP	6.15 AM	8.45 PM	699.4		TO-R	**EL CENTRO**	9.1	s 8.15 AM	s 6.50 PM
						E. 5.6 — W. 4.6			
Yard Limits 69 P	f 6.30	f 8.52	704.0			**HEBER**	4.5	f 7.58	f 6.37
						E. 4.9 — W. 4.2			
Yd. Limits 175 BKWOYP	s 6.40 AM	s 9.10 PM	708.5		TO-R	**CALEXICO**	0.0	7.50 AM	6.25 PM
	Arrive Daily Ex. Monday	Arrive Daily				(41.0)		Leave Daily	Leave Daily Ex.Saturday
	(0.25) 21.84	(0.25) 21.84				Time over District Average Speed per Hour		(0.25) 21.84	(0.25) 21.84

Rule 5—Schedule time and train orders for first class trains at Calexico apply at station sign.

SD&AE trains 362, 363, 451 and 452 use SP main track between junction switch and SP station, El Centro, moving with caution. Schedule time and train orders for SD&AE trains applies at junction switch.

Engines using SD&AE main track within El Centro yard limits must clear No. 362 due to leave Wilsie 8:23 PM, and No. 363 due to leave El Centro 8:25 AM, and must avoid unnecessary delay to No. 452 due to leave Wilsie 5:40 AM and No. 451 due to leave El Centro 7:01 PM.

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Estelle..........	672.0	......
Rockwood..........	681.0	......
Grape..........	690.3	......

CALEXICO SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓		Time Table No. 183 July 8, 1945 Westmorland Branch STATIONS	Westward Distance from Westmorland ↑
Yd. Lmts. 90 YP	675.7	TO	**CALIPATRIA**	12.6
			12.6	
	688.3		**WESTMORLAND**	0.0
			(12.6)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Verdant..........	679.1	......
Shamrock..........	680.6	......
Fondo..........	683.1	......

CALEXICO SUBDIVISION

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓		Time Table No. 183 July 8, 1945 Sandia Branch STATIONS	Westward Distance from El Centro ↑
Yd. Lmts. 90 YP	675.7	TO	**CALIPATRIA**	38.0
			27.8	
Yd. Limits YP	703.5		**HOLTVILLE**	10.2
			10.2	
Yd.Lts.87 BKWYP	713.7	TO-R	**EL CENTRO**	0.0
			(38.0)	

ADDITIONAL STATIONS

NAME	Mile Post	Capacity
Turn..........	681.8	......
Munyon..........	686.8	......
Butters..........	689.6	11
Moss..........	689.8	......
Orita..........	691.7	......
Curlew..........	694.2	......
Sandia..........	697.5	......
Fuller..........(Spur)	699.4	9
Rico..........	704.5	......
Meloland..........	707.6	......

VENTURA SUBDIVISION

Capacity of sidings in car lengths	Eastward Distance from San Francisco ↓		Time Table No. 183 July 8, 1945 Burbank Branch STATIONS	Westward Distance from Burbank ↑
85 WYP	445.5	TO	**CHATSWORTH** 9.6	21.3
	455.1		**ENCINO** 3.3	11.7
W	458.4	See Note	P. E. Ry. CROSSING **VAN NUYS** 4.4	8.4
	462.8		**NORTH HOLLYWOOD** 4.0	4.0
Yard Limits YP	466.8		**BURBANK**	0.0
			(21.3)	

Joint track with Pacific Electric Ry. between MP 459.9 and North Hollywood. Movements governed by A-P. B. system — see special instructions.

ADDITIONAL STATIONS		
NAME	Mile Post	Capacity
Canoga Park..........	449.2	......
Tarzana..............	453.4	......

Derail on U. S. Base Hospital spur, Encino, 20 feet from main track switch.

SALTON SUBDIVISION

EASTWARD

FIRST CLASS

Capacity of sidings in car lengths	6 Argonaut Leave Daily	4 Golden State Limited Leave Daily	370 Leave Daily	44 Californian Leave Daily	362 San Diego Passenger Leave Daily	2 Sunset Limited Leave Daily	Distance from San Francisco	Automatic Block System		Time Table No. 183 July 8, 1945 STATIONS	
Indio Yard BKWOYP	11.35PM	11.05PM	9.50PM	9.40PM		1.15PM	610.9		TO-R	**INDIO** E.0.4	
							611.3		TO-R	**INDIO YARD** E.1.0	
							612.3		TO-R	**EAST INDIO** E.1.8	
82 P	f11.42	11.14	9.58	9.47		f 1.25	614.4		TO	**COACHELLA** E.2.8	
120 P	s11.47	11.21	10.04	9.53		f 1.32	618.0		TO	**THERMAL** E.6.4	
140 WP	**11.54PM**	11.28	10.11	10.00		f 1.41	624.1		TO	**MECCA** E.5.0	
134 P	12.01AM	**11.34**	10.17	10.06		1.47	628.8			**CALEB** E.4.4	
131 P	12.07	11.41	10.23	10.11		1.53	633.3		TO	**MORTMAR** E.4.4	
102 P	12.12	11.46	10.28	10.16		1.59	637.8			**SALTON** E.4.5	
66 P	12.18	11.51	10.34	10.21		**2.06**	642.1			**DURMID** E.4.3	
103 P	12.24	11.57PM	10.40	10.26		2.13	646.8		TO	**BERTRAM** E.4.3	
100 P	12.29	12.02AM	10.46	10.31		2.19	651.1			**POPE** E.4.3	
134 P	12.35	12.08	**10.52**	**10.37**		2.25	655.6			**FRINK** E.3.6	
105 P	12.40	12.14	10.57	10.42		2.31	660.1		TO	**WISTER** E.3.4	
68 P	12.45	12.19	11.02	10.46		2.36	663.5			**MUNDO** E.3.5	
Yard Limits 148BKWOYP	s 1.05	s12.35	11.15	f10.58		s 2.47	667.5		TO-R	**NILAND** E.4.4	
64 P	1.10	12.42	11.21	11.04		2.53	671.7			**FLOWING WELL** E.2.7	
111 P	1.15	12.47	11.26	11.08		2.58	674.4			**IRIS** E.4.5	
132 P	1.22	12.53	11.32	11.14		3.04	678.5			**TORTUGA** E.5.5	
101 WP	1.30	12.59	11.38	11.20		3.10	684.6		TO	**AMOS** E.5.9	
68 P	1.37	1.06	11.45	11.26		3.17	690.1			**ACOLITA** E.5.0	
102 P	1.45	1.12	11.51	11.32		3.23	695.6			**MESQUITE** E.2.7	
128 P	1.51	1.16	11.55PM	11.36		**3.27**	698.1		TO	**GLAMIS** E.5.2	
101 P	1.58	1.23	12.02AM	11.42		3.34	703.0			**RUTHVEN** E.6.4	
63 P	2.06	1.31	12.10	11.49		3.42	709.4			**CLYDE** E.2.8	
127 P	**2.14**	1.36	12.15	11.52		3.46	712.3			**CACTUS** E.4.4	
99 P	2.21	1.42	12.22	11.57PM		f 3.52	716.6		TO	**OGILBY** E.5.5	
130 P	**2.31**	1.48	12.28	12.03AM		3.58	722.7			**KNOB** E.4.3	
P	**2.42**	1.53	12.35	12.10	11.50PM	4.05	726.1			**ARAZ JCT.** 0.9	Double Track
P							727.0		TO	**ARAZ** 4.9	
Yuma yard BKWOTYP							731.9			**COLORADO** 0.8	
	s 3.00AM	s 2.15AM	s 1.00AM	s12.30AM	s12.05AM	s 4.20PM	732.7		TO-R	**YUMA**	
	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily				(121.8)	
	(3.25) 35.65	(3.10) 38.98	(3.10) 38.98	(2.50) 42.98	(0.15) 26.40	(3.05) 39.52				........Time over District........ ......Average Speed per Hour......	

No. 2 stop at Thermal daily except Sunday to load U. S. Mail.

No. 2 stop on flag at Amos Tuesdays and Glamis Saturdays to receive and discharge non-revenue passengers.

No. 2 stop if necessary, to unload baggage and express Tuesdays and Fridays Flowing Well to Amos inclusive, Wednesdays and Saturdays Acolita to Knob inclusive.

No. 2 stop at Glamis when necessary, exchange Parcel Post.

Rule 5. Schedule time and train orders for first-class trains at Indio apply at station sign.

SALTON SUBDIVISION

WESTWARD

Time Table No. 183

July 8, 1945

	STATIONS	Distance from Yuma	FIRST CLASS						SECOND CLASS			
			3	5	43	363	371	1	815	817	819	839
			Golden State Limited	Argonaut	Californian	San Diego Passenger		Sunset Limited	Freight	Freight	Freight	Freight
			Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily	Arrive Daily
TO-R	INDIO W. 0.4	121.8	s 4.36 AM	s 5.03 AM	s 6.55 AM		s 8.20 AM	s 2.50 PM				
TO-R	INDIO YARD W. 1.0	121.3							6.25 AM	12.04 PM	6.15 PM	12.20 AM
TO-R	EAST INDIO W. 2.7	120.3										
TO	COACHELLA W. 3.2	118.3	4.27	4.56	6.46		8.10	2.41	6.15	11.54 AM	6.04	12.09
TO	THERMAL W. 6.5	114.7	4.21	4.50	6.40		8.05	2.35	6.09	11.48	5.58	12.03 AM
TO	MECCA W. 5.0	108.6	4.13	4.43	f 6.33		7.58	2.29	6.00	11.39	5.49	**11.54 PM**
	CALEB W. 4.4	103.9	4.07	4.37	6.27		7.52	2.23	5.53	11.33	5.43	**11.34**
TO	MORTMAR W. 4.3	99.4	4.01	4.31	6.21		7.46	2.17	5.46	11.26	5.36	11.27
	SALTON W. 3.9	94.9	3.55	4.25	6.15		7.40	2.11	5.39	11.19	5.29	11.20
	DURMID W. 4.7	90.6	3.50	4.20	6.10		7.35	**2.06**	5.32	11.12	5.22	11.13
TO	BERTRAM W. 4.3	85.9	3.44	4.14	6.04		7.29	1.54	5.25	11.05	5.15	11.06
	POPE W. 4.7	81.6	3.39	4.09	5.59		7.24	1.49	5.18	10.58	5.08	10.59
	FRINK W. 4.7	77.1	3.33	4.03	5.53		7.18	1.43	5.11	10.51	5.01	10.52 10.31
TO	WISTER W. 3.1	72.6	3.26	3.57	5.46		7.11	1.36	5.04	10.44	4.54	10.24
	MUNDO W. 4.1	69.2	3.22	3.52	5.42		7.07	1.32	4.57	10.37	4.47	10.17
TO-R	NILAND W. 3.8	65.2	s 3.15	s 3.47	s 5.36		7.00	s 1.25	4.50	10.30	4.40	10.10
	FLOWING WELL W. 3.2	61.0	3.03	3.36	5.29		6.51	1.11	4.31	10.09	4.19	9.56
	IRIS W. 4.7	58.3	2.58	3.31	5.25		6.47	1.08	4.25	10.03	4.13	9.50
	TORTUGA W. 5.2	54.2	2.53	3.26	5.20		6.41	1.03	4.17	9.55	4.05	9.43
TO	AMOS W. 5.6	48.1	2.47	3.19	5.13		6.34	12.56	4.07	9.45	3.55	9.34
	ACOLITA W. 5.4	42.6	2.41	3.12	5.07		6.28	12.50	3.58	9.35	3.45	9.25
	MESQUITE W. 2.9	37.1	2.35	3.06	5.01		6.22	12.44	3.49	9.25	3.35	9.17
TO	GLAMIS W. 4.9	34.6	2.31	3.02	4.57		6.17	12.40	3.42	9.19	**3.27**	9.11
	RUTHVEN W. 6.1	29.7	2.25	2.56	4.52		6.11	12.34	3.32	9.09	3.08	9.04
	CLYDE W. 3.5	23.3	2.19	2.49	4.45		6.05	12.27	3.22	8.58	2.58	8.55
	CACTUS W. 4.0	20.4	**2.14**	2.44	4.40		5.59	12.23	3.12	8.48	2.48	8.48
TO	OGILBY W. 5.8	16.1	2.08	2.38	4.34		5.53	12.18	3.03	8.40	2.40	8.40
	KNOB W. 3.0	10.1	2.01	**2.31**	4.26		5.46	12.11	2.55	8.32	2.32	8.32
	ARAZ JCT. 0.9	6.6	1.55	2.25	4.20	5.15 AM	5.40	12.05 PM	**2.42**	8.20	2.20	8.20
TO	ARAZ 4.9	5.7										
	COLORADO 0.8	0.8										
TO-R	YUMA	0.0	1.45 AM	2.15 AM	4.10 AM	5.00 AM	5.30 AM	11.55 AM	2.20 AM	8.00 AM	2.00 PM	8.00 PM
	(121.8)		Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily	Leave Daily
	Time over District Average Speed per Hour		(2.51) 42.73	(2.48) 43.50	(2.45) 44.29	(0.15) 26.40	(2.50) 42.98	(2.55) 41.76	(4.05) 29.82	(4.04) 29.83	(4.15) 28.54	(4.20) 27.90

Automatic Block System

Double Track

No. 1 stop at Thermal daily except Sunday to load U. S. Mail; and stop on flag at Mecca Fridays only to receive passengers.

No. 1 stop on flag at Ogilby Mondays, Amos Tuesdays and Glamis Saturdays to receive and discharge non-revenue passengers.

No. 1 stop at Clyde and Iris, and No. 3 at Amos and Flowing Well each Monday, Wednesday and Friday, if necessary to unload baggage and express.

Rule 5. Schedule time and train orders for first-class trains at Indio apply at station sign.

FIRESTONE PARK SUBDIVISION

Time Table No. 183

July 8, 1945

San Pedro Branch

Capacity of Sidings in Car Lengths	Eastward Distance from San Francisco ↓		STATIONS	Westward Distance from San Pedro ↑
L. A. Yard WYP	489.1	TO-R	FIRESTONE PARK 2.7	16.4
	491.8		P. E. Ry. CROSSING LYNWOOD 2.3	13.7
55	494.1		COMPTON 2.1	11.4
I	496.2		DOMINGUEZ TOWER P. E. Ry. CROSSING 3.8	9.3
33	500.0		WATSON 0.9	5.5
I	500.9		WILMINGTON (Anaheim Blvd.) TOWER A. T. & S. F. Ry. CROSSING 0.5	4.6
IYP	501.4		WILMINGTON (Anaheim Blvd.) P. E. Ry. CROSSING (Island Crossing) 0.7	4.1

Trackage east of Anaheim Boulevard is under jurisdiction of Harbor Belt Line Railroad. Eastward trains must communicate with yardmaster, Wilmington, before leaving Wilmington (Anaheim Boulevard.)

Yard Limits		502.1		ANAHEIM BLVD. 0.8	3.4
	BKWOP	502.9	TO-R	P. E. Ry. CROSSING (Stop) WILMINGTON 1.6	2.6
	I	504.5		SAN PEDRO DRAWBRIDGE 1.0	1.0
		505.5		SAN PEDRO	0.0
				(25.7)	
				Time over District Average Speed per Hour	

ADDITIONAL STATIONS		
NAME	Mile Post	Capacity
Southgate (Tweedy Blvd.)	490.3	.....
Elftman	497.7	.....
Blinnville	502.1	.....

RULE 2. Watch inspectors:

S. A. Pope, Manager of Time Service, 65 Market St., San Francisco.

Los Angeles	Baehr-Bakula, Inc., 103 Pacific Electric Bldg. Geo. D. Davidson Co., 445 S. Spring St. O. H. Patzer, 2708 North Broadway Ralph Laraway, 1226 San Fernando Rd.		
Huntington Park	James Podmore	Colton	C. G. Miller
Glendale	John R. Leaney, 112 W. Broadway	Redlands	Howard S. Smith
		Banning	B. B. Felts
Temple City	J. A. Peters	Indio	J. A. Vest
Santa Ana	R. H. Ewert	Yuma	J. H. Huber
Oxnard	Jack Davis	Van Nuys	C. H. Berggren
Santa Barbara	H. V. Weirum	Ventura	G. J. Adamson
San Pedro	Perham's	Brawley	F. T. De Arman
Long Beach	Leo Miller	El Centro	J. L. Bledsoe
Pasadena	J. Herbert Hall Co.	Calexico	E. E. Pinnell
Pasadena	Geo. W. Collis	Fillmore	Duard E. Goble
Alhambra	H. E. Wellman	San Bernardino	Hobart W. Hanf
Covina	J. Howard Boal	Riverside	F. S. Fisher
Pomona	W. R. Parsonage		

RULE 2 (A). Watches subject to inspection must be presented monthly, between first and fifteenth, instead of semi-monthly, to a designated inspector.

RULE 10. Between Grand Terrace and Colton, signals must be placed on the right, facing westward.

RULE 10 (H). Where yellow signals are displayed within limits of a length of track over which a maximum speed is designated in train order or time-table bulletin and no maximum speed is otherwise specified for the particular section of track protected by these yellow signals, trains must not exceed fifteen miles per hour thereover.

RULE 10(J). Round yellow slow boards indicate by black figures the speed restrictions applying to trains which consist of streamlined cars only (other than Lark equipment) with GS, P-7-10-12, or P-8 (except eng. 2470) class engines.

Mile Post location of slow boards which restrict the speed of trains, as indicated on slow board, while engine of such train is passing distant signal three-fourths mile beyond the slow board:

Eastward						Westward
			SANTA BARBARA-BURBANK JCT.			
370.84	391.08	418.31	....	424.92	387.41	382.94
374.89	395.59	421.44	....	391.08	384.89	378.83
379.86	405.66	439.26	....			
381.79			....			
			BURBANK JCT.-LOS ANGELES			
475.13			....			475.87
			LOS ANGELES-COLTON			
537.40			....			488.10
			INDIO-YUMA			
622.12	649.09	693.47	....	728.84	696.98	648.39
636.10	658.46	707.93	....	727.59	669.19	643.70
640.48	661.94	724.45	....	718.50	665.16	639.82
644.76	665.31	730.42	....	710.90	662.13	626.16
			....	705.02	652.66	619.59
			....			616.37

Mile Post location of slow boards which restrict the speed of trains, as indicated on slow board, while engine of such train is passing the home signal three-fourths mile beyond the slow board:

Eastward	INDIO-YUMA	Westward
666.75	....	668.04

RULE 14 (d). As specified below, —— —— —— —— o sounds will be indication that flagman may return from west:

Saugus	on Santa Paula Branch.
Burbank Jct.	on Northridge Line.
Burbank	on Burbank Branch.
Mission Jct.	on River Station Tower line.
Pomona	on Covina Branch.
Araz Jct.	on Inter-Cal. line.

RULE 14 (e). As specified below, —— —— —— —— —— —— sounds will be indication that flagman may return from east:

Calipatria	on Sandia and Westmorland Branches.
Niland	on Calexico line.
Bryn Mawr	on Redlands Branch.
Colton	on Riverside Branch.
Pomona	on Chino Branch.
Bassett	on Covina Branch.
Alhambra	on Pasadena Branch.
Chatsworth	on Burbank Branch.
Ventura Jct.	on Ojai Branch.
Montalvo	on Santa Paula Branch.
Wilmington (Anaheim Blvd.)	on Long Beach Branch.
Firestone Park	on Santa Ana Branch.
West Anaheim	on Los Alamitos Branch.
Tustin Jct.	on Tustin Branch.
Stanton Jct.	on Los Alamitos Branch.
River Station Tower	on Mission Jct. line.

RULE 14(m). Whistle will not be sounded one mile before reaching stations between Los Angeles and Alhambra and between Los Angeles and Burbank Jct.

RULE 17. Mars Signal Light on engines shall be used when engine is moving at night, and in foggy or stormy weather. It must be dimmed or extinguished approaching passenger stations, and at other points as prescribed by rules.

RULE 21 (C). Indicators on extra trains will be displayed during time train is in Colton yard.

Indicators may be displayed on incoming engines at Indio until they arrive at roundhouse.

RULE 26. Colton: Special signal at each end PFE tracks 5, 6 and 7, and at switch to spur, governing movements on those tracks as follows:

Blue: Track may be entered, but cars must not be coupled to, or moved.
Yellow: Proceed with caution.
Red: Must not enter PFE shed.
Not lighted: General foreman of ice plant must be contacted for instructions before entering tracks.

RULE S-72. Westward trains are superior to trains of the same class in the opposite direction.

RULE 82 (A). Trains must obtain clearance before leaving:

Indio	First-class trains.
Indio Yard	Westward trains, except first-class.
East Indio	Eastward trains, except first-class.
Niland	All trains.

Trains to I-CRy must obtain separate I-C and Los Angeles Division clearances at Yuma.

Trains to San Joaquin Division must obtain separate San Joaquin Division and Los Angeles Division clearances and need not obtain clearance at Burbank Jct., if properly cleared by train-order signal.

Trains from San Joaquin Division need not obtain clearance at Burbank Jct., if properly cleared by train-order signal.

Train-order office and register at Santa Barbara located at freight station. Westward first-class trains receiving train-orders, clearance and instructions there must deliver to relieving crew at passenger station.

Train-order office and register at Colton located at yard office.

RULE 83. Identification may be made by eastward trains on double track between Santa Barbara and East Santa Barbara to be applied at end of double track. Reduce speed sufficiently to permit identification and comply with Rule 14 (k).

Identification may be made by westward trains on double track between Yuma and Araz Jct., to be applied at end of double track. Reduce speed sufficiently to permit identification and comply with Rule 14 (k).

RULE 83 (A). At the following station only trains indicated will register:

Los Angeles Yard, originating or terminating, except light engines to or from Ventura and Pomona Subdivisions.

RULE 83 (B). At open train-order offices trains may register by ticket as follows:

Colton	First-class
Colton	Eastward second-class and extras arriving
Indio, Indio Yard and East Indio	First-class
Niland	First and second-class
Santa Barbara	First-class
Firestone Park	Westward trains

Light engines arriving Indio may register by ticket at Indio Yard train-order office.

When a regular train or section of schedule is checked at Los Angeles LAUPT it will not be necessary to obtain check of the same train at Burbank Jct. when moving to San Joaquin Division.

RULE 92. First sentence does not apply arriving Los Angeles LAUPT.

RULE 93. Yard limits in which the provisions of Rule 93 will apply, except within C.T.C. limits, are established at the following points:

West MP		East MP
508.37	Anaheim	510.68
	" (Los Alamitos Br.)	509.26
684.11	Brawley	688.24
706.40	Calexico	708.88
674.52	Calipatria	676.77
	" (Sandia Br.)	676.51
536.51	Colton	541.14
	" (Riverside Br.)	540.70
551.00	Crafton	
697.83	El Centro	700.89
712.38	" (Sandia Br.)	
423.54	Fillmore	425.62
703.05	Heber	704.84
708.53	Holtville	
694.44	Imperial	696.62
607.85	Indio	613.12

West MP		East MP
462.32	Los Angeles (Coast line)	
471.20	" (Saugus-Alhambra line)	488.69
	" (Burbank Br.)	466.19
	" (Pasadena Br.)	488.24
	" (San Pedro Br.)	489.90
	" (Santa Ana Br.)	489.99
403.25	Montalvo (Santa Paula Br.)	404.83
666.09	Niland	668.69
668.27	" (Calexico line)	
519.20	Ontario	521.32
406.61	Oxnard	409.12
512.18	Pomona	515.71
513.30	" (Covina Br.)	
547.29	Redlands, 2nd Street	548.51
544.85	Riverside	
502.01	San Pedro	
516.15	Santa Ana	517.68
369.16	Santa Barbara	373.71
412.57	Santa Paula	416.53
449.41	Saugus	452.60
448.17	" (Santa Paula Br.)	
397.13	Ventura	399.45
	" (Ojai Br.)	398.16
731.51	Yuma	737.83

Yard limit boards located to left of track:
Eastward on San Joaquin Division, Burbank Jct.
Westward at Colton.

Trains and engines must not move against current of traffic on double track within Los Angeles yard limits, unless authorized by yardmaster or his representative, except that such movements may be made in the territory named below, as follows:

In either direction between Division Street and the connection at west end of "A" Yard, when proceed signal is given by switchtender at either limit, white flag or lamp.

Eastward from Division Street to Dayton Ave. Tower, when proceed signal is given by switchtender at Division Street, white flag or lamp.

Westward from Dayton Ave. Tower to Division Street, when interlocking signal indicates "Proceed."

In either direction between Dayton Ave. Tower and River Station Tower on freight leads, when interlocking signal indicates "Proceed."

In either direction between Butte Street Jct. and Firestone Park on freight leads, when proceed signal is given by switchtender at either limit, white flag or lamp.

Before such hand signal is given, or before interlocking signal is set to indicate "Proceed," switchtender or signal operator, as the case may be, must arrange with other switchtenders or signal operators in the territory over which movement is to be made, to prevent any other train or engine entering such track until the authorized movement against current of traffic is completed.

In addition, for movements eastward on westward freight lead, or westward on eastward freight lead between Dayton Ave. Tower and River Station Tower in either direction, signal operator must secure permission from yardmaster at Bull Ring for such movements.

Approach west switch "A" unit, Los Angeles Yard on third track south of Glendale Tower with caution. Call for signal from switchtender. If not received train must be stopped west of spot board 100 feet west of Fletcher Drive. When train consists of over 71 cars switchtender will permit train to move ahead far enough for rear end to clear Glendale Tower interlocking limits, and crew must then cut Fletcher Drive crossing, pulling the lead cut sufficient distance to clear spot board 100 feet east of crossing.

Cars must not be left standing between spot boards unless member of crew protects vehicular traffic on crossing.

Westward trains before entering "A" unit, Los Angeles Yard, must sound whistle signal —— o —— unless switches are lined for the route to be used and a proceed signal is received from switchtender.

RULE 95. Sections of eastward first-class schedules changing signals at Colton must do so at train-order office.

Eastward trains from San Joaquin Division holding train-order authority to display signals for following section to Burbank Jct. are authorized to display signals to terminal station of schedule on Los Angeles Division.

No. 362 and sections thereof may assume similar schedule or sections of schedule at Araz Jct. as authorized into Araz Jct. on Inter-California Ry. without clearance or further train order authority.

Sections of schedules may display signals and operate from points within the Los Angeles yard limits, except when originating at LAUPT or Los Angeles Yard, as instructed by the Chief Train Dispatcher, and obtain train order authority for such operation on arrival at Alhambra or Burbank Jct., as the case may be.

RULE 97. Extra trains must not run via Santa Paula, Burbank, or Sandia branches unless train order so specifies.

RULE D-97 (A). Will apply between following points:

Santa Barbara and East Santa Barbara.
Burbank Jct., Los Angeles and Alhambra via East Bank Jct.
Araz Jct. and Yuma.

RULE 98. Cars must not be kicked or shoved over railroad crossings not protected by interlocking, unless movement is properly protected.

Trains and engines must approach with caution, and may move over following crossings without stopping, if crossing clear and no movement approaching on intersecting line:

Los Angeles—AT&SFRy industrial track over Gladding McBean spur, Wilson spur, and Eureka Supply spur.
Pasadena Br.—AT&SFRy at MP 491.2.
Colton—PERy at passenger station.
Van Nuys—PERy (Must not exceed 8 MPH).
Los Angeles—PERy at MP 487.5 (Must not exceed 6 MPH).
San Pedro Br.—PERy at MP 491.3 (Must not exceed 6 MPH).
Long Beach Br.—MP 501.9 AT&SFRy crossing Texas Co. spur.

Stop clear of following crossings and send flagman ahead, who must ascertain that no movement approaching on intersecting line before giving signal to proceed:

Los Angeles—LARy Boyle spur on Santa Fe Ave.
Los Angeles—LARy Mateo St. at east end coach yard.
Pasadena Br.—PERy at MP 488.5.
Tustin Br.—AT&SFRy at MP 514.7.
Los Alamitos Br.—PERy at MP 514.0.
Long Beach Br.—PERy at MP 502.4.

Stop clear of following crossings, then proceed if no movement approaching on intersecting line:

Los Angeles—LARy Davies spur on Second St.
Los Angeles—LARy Bernard spur on Central Ave.
Ontario—UPRR on old Chino line spur. (Has electrically locked derail. Instructions posted on inside of lock-box.)
Covina Br.—PERy at MP 501.0.
Covina Br.—PERy at Lone Hill.
San Pedro Br.—PERy at MP 502.7.
Santa Ana Br.—PERy Griffith lumber spur at Santa Ana.
Santa Ana Br.—West leg of wye at MP 517.1.
Santa Ana Br.—East leg of wye at MP 517.2.

Stop clear of lead to PFE yard Colton on west leg of wye, and on east leg of wye, unless proceed signal received from herder. In absence of herder member of crew must be sent ahead, who must ascertain that no movement approaching on intersecting line before giving signal to proceed.

RULE 99 (C). Will apply on Santa Paula and Santa Ana branches.

RULE 103 (A).

Trains must stop and traffic on highway be protected by member of the train crew over the following street crossings:

Edison spur, MP 446.2 (Santa Paula Br.)-Telegraph road. (Movements to be made only during daylight hours.)
Limoneria Spur at Limco—Telegraph Road on spur.
Industrial—Fletcher Drive, on Van de Kamp spur.
Los Angeles yard—Wilson St., Mateo St.
South Gate (Atlantic Blvd.)—Independence Avenue, on Philadelphia Quartz Co. spur.
Lynwood—Truck Boulevard, on Pacific Iron and Steel Co. spur.
Riverside—Orange Ave., Eighth St.
Riverside—Crossing bells located at Seventh and Ninth Streets are manually controlled. Switch located in box on telegraph pole east of freight station. Crossing bells must be in operation when any train movements are made over crossings, unless protected by members of train crew on both sides of train, before and while movements are being made over crossings.
Redlands 2nd Street—Orange Street, Second Street.
Redlands 2nd Street—Fourth Street on Mutual Orange Assn. spur.
Anaheim—Los Angeles Street.
Santa Ana—Fourth Street.
Alhambra—Mission Road on track leading to Edison Plant.
Indio—Highway California Date Growers Assn. spur.
Yuma—All crossings in old yard.
Brawley—When shoving cars eastward over K St. on Even drill or Standard Oil spur. When engine ahead, stop, sound whistle signal 14(l) and if crossing clear, proceed.

El Centro—Before pushing or backing cars on house track or drill tracks over Main Street crossing, flagman must be placed on crossing until leading car has passed.

Santa Barbara—Rear brakeman on No. 99 must remain behind train to protect traffic over Helena St. while slack is being taken in starting train. After starting, train must move slowly to permit brakeman to reach vestibule and until proceed signal received.

RULE 104. The normal position of rigid switches at junction points is as follows:

Ventura Jct.	Ojai Br., for Ventura line.
Montalvo	Santa Paula Br., for siding.
Chatsworth	Burbank Br., for siding.
North Hollywood	Burbank Br., for PERY main track.
MP 459.9	Burbank Br., for PERY main track.
Burbank	Burbank Br., for eastward main track on L. A. line.
Alhambra	Pasadena Br., for house track.
Bassett	Covina Br., for house track.
Pomona	Covina Br., for Ontario line.
Pomona	Chino Br., for siding.
Colton	Riverside Br., for PFE yard.
Bryn Mawr	Redlands Br., for team track.
Niland	Calexico subdivision, for Salton line.
Calipatria	Westmorland Br., for Calexico line.
Calipatria	Sandia Br., for Calexico line.
Holtville	Holtville Interurban main track for Sandia Br.
El Centro	Interchange track, for SD&AE main track.
El Centro	Sandia Br., for Calexico line.
Baldwin Park	Covina Br., for PERy main track.
Lone Hill	Covina Br., for SP main track.
La Verne	Covina Br., for PERy main track.
Ganesha Jct.	Covina Br., for SP main track.
Saugus	Santa Paula Br., for westward siding.
Colton	PERy junction switch on Riverside Br., for SP main track.
Riverside Jct.	PERy junction switch for SP main track.
Naud Jct.	Mission Jct. line for westward track on River Station Tower line.
Butte St. Jct.	Butte St. yard line switches, and crossover switches may be left as used.
Firestone Park	Santa Ana Br., for westward track on L. A. line.
Wilmington (Anaheim Blvd.)	Long Beach Br., for San Pedro line.
West Anaheim	Los Alamitos Br., for Santa Ana line.
Tustin Jct.	Tustin Br., for Santa Ana line.
Stanton Jct.	Smeltzer Br., for Los Alamitos line.

Inside crossover switch west end team track, Ventura, must be left lined for the straight track.

DERAILS IN MAIN TRACK

TUSTIN BRANCH

Tustin—10 feet east of east switch.

SANTA ANA BRANCH

Dyer—MP 519.67.

COVINA BRANCH

Bassett—120 feet west of water tank, MP 497.52.
Pomona—50 feet west of west line of Rebecca St., MP 514.8.

REDLANDS BRANCH

Crafton—628 feet west of west switch, MP 551.01.
Crafton—930 feet from end of track, MP 551.52.
Redlands, 2nd Street—West end of Mill Creek bridge, MP 547.33.

SANDIA BRANCH

Calipatria—174 feet east of junction switch, MP 676.05.

WESTMORLAND BRANCH

Calipatria—171 feet east of junction switch, MP 676.05.

OJAI BRANCH

Ventura Jct.—250 feet east of junction switch.
Ojai—6 feet west of initial switch.

SANTA PAULA BRANCH

Montalvo—350 feet west of switch to M.O.D. track.

RULE 105. When switch of siding or other track to be entered must be thrown by employe on train, stop must be made to allow time for lining switch.

Oxnard—West switch to siding located at Signals 4077 and 4078. Inside switch on siding must be left lined for drill track.

Northridge—Track north of main track is westward siding;
Track south of main track is eastward siding.
Raymer—Track north of main track is eastward siding;
Track south of main track is westward siding.
Saugus—Track east of station building is westward siding;
Track west of station building is eastward siding.

Pomona—That portion of siding between first crossover east of Signal 5136 and first crossover east of passenger station is designated as Passenger Siding, and must not be unnecessarily blocked by freight trains.

Indio—Westward first-class and passenger trains required to clear main track will use connection opposite yard office.

To avoid delay to opposing trains, eastward trains taking siding at Camarillo; and westward trains at Oxnard; will stop back of the home signal until the switch is thrown to enter the siding.

RULE 221. First sentence of third paragraph is amended as follows: "When a train order is to be delivered to an approaching train, or orders are held for any other train in the same direction, except those originating, the operator must not clear the signal."

Light will not be displayed in train-order signals on Firestone Park Subdivision east of Firestone Park; nor on Santa Paula and Covina branches except when train-order operator is on duty.

Los Angeles Yard is a train-order office only for trains originating.

Indio is a train-order office only for first-class trains.

Indio Yard is a train-order office only for westward trains, except first-class.

East Indio is a train-order office only for eastward trains, except first-class.

RULE D-251. Will apply as follows:

On both tracks between Yuma and Araz Jct.
On both tracks between Burbank Jct. and Alhambra.

RULE 297. Following paragraph is added:

A train, if delayed in the block, must proceed with caution to the next signal.

RULE 505. AUTOMATIC BLOCK SYSTEM

Block signals in addition to those shown in brackets on schedule pages are in operation as follows:

Eastward and westward freight main tracks between Los Angeles Yard Office and Dayton Ave. Tower.

North Broadway Bridge San Pedro line	Westward track
East end "A" freight shed San Pedro line	Eastward track
Firestone Park	Governing westward trains

When stopped by Signals 4789, 4791, 4793 and 4790 Los Angeles Yard, trains and engines may proceed when signal received from switchtender, if signal does not clear,

West switch of crossover at Arroyo Jct., has electric switch lock. Instructions for operation posted on inside of lock-box door.

Push buttons and lights on mast of signal at east end sidings at Oxnard and Walnut, and each end of siding Camarillo.

Train occupying main track may clear signal governing movements from siding by pressing button with number corresponding to the number of signal governing movements from the siding. Train on the siding to let train on main track pass should not pass overlap post 500 feet from signal governing movement from siding. If necessary to pass overlap post, press button with number corresponding to number of signal governing movements on main track.

Instructions for operating signals are located inside of push button box.

When signals 6116, 6118, 6119 and 6123 at Indio; and 7085 at Calexico are found in "stop" position, train, after stopping, may proceed with caution, not exceeding 12 MPH to next home signal.

When block Signal 4841 east of Taylor Jct. indicates "stop", a member of the crew of freight trains will communicate with signal operator at Mission Tower by telephone located on the signal, and be governed by his instructions.

When special type signal mounted on mast of Automatic Signal 4864 indicates "stop", eastward freight trains will be brought to a stop west of sign reading "SPECIAL SIGNAL LIMIT" located 200 feet west of Westminster Avenue crossing MP 487.3, and a member of the crew will communicate with Alhambra Operator by telephone located at Westminster Avenue and be governed by his instructions before proceeding.

Special signal, normally dark, located at MP 513.6 immediately west of Hamilton Boulevard, Pomona, may display flashing white aspect to authorize eastward movement on siding east of Hamilton Boulevard. Eastward trains, except first-class, taking siding at Pomona will not proceed east of Hamilton Boulevard except on receipt of flashing white aspect of above special signal or under train order or schedule authority.

Push button on Signal 5076 at Walnut, to be used to obtain proceed indication of Signal 5076 in event a reverse movement is made on main track within siding limits.

Upper unit of Signal 5138 may display flashing white light to authorize movement on siding east of Hamilton Boulevard, Pomona. Lower unit will indicate proceed when route through crossover is lined and block clear. Eastward trains except first-class, entering siding Pomona, must not pass Hamilton Boulevard unless flashing white light displayed in this signal for movement on siding, or train order or time-table authority authorizes movement to main track.

GOVERNING OPERATION OF SIGNALS, ARAZ JCT.

Araz Jct. Signal 7275 governs westward movement through east crossover and against current of traffic on eastward main track to Signal P-7263 and will indicate proceed after both switches of east crossover are set for crossover movement and block is clear.

Signal P-7265 governs westward movement through crossover and against current of traffic on eastward main track to Signal P-7261, and will indicate proceed after east switch to crossover is set for crossover movement and block is clear.

Trains and engines will operate between Signal P-7265 and P-7261 against current of traffic on eastward main track on signal indication which supersedes the superiority of trains.

Signal P-7263 governs westward movement on eastward track to Signal P-7261.

Signal P-7261, normally stop, governs westward movement as follows: green, movement on eastward main track via Knob; yellow, movement on eastward main track via I-CRy. To obtain signal for movement on eastward main track via Knob, operate push button No. 7261 in box on signal case west end of Bridge 726.08. If signal does not indicate proceed in three minutes, be governed by Rule 509(F). To obtain signal for movement to I-CRy, set the junction switch for that movement.

Signal P-7261 may be released and proceed indication secured on Signal P-7259 by operating push button No. 7259 in box located on signal case of Signal P-7259, waiting three minutes for time release.

Eastward train via Knob, finding Signal P-7260 in proceed position and desiring to give precedence to eastward train from I-CRy, will operate push button No. 7632 in box located on case of Signal P-7260.

Eastward train via Knob, finding Signal P-7260 indicating stop account eastward train via I-CRy occupying approach circuit and desiring to proceed on eastward track ahead of train on I-CRy main track, will operate push button No. 7260 in box located on case of Signal P-7260.

Eastward train via I-CRy, finding Signal P-7632 in proceed position and desiring to give precedence to eastward train via Knob, will operate push button No. 7260 in box located on case of Signal P-7632.

Eastward train via I-CRy, finding Signal P-7632 indicating stop account eastward train via Knob occupying approach circuit and desiring to proceed on eastward track ahead of train from Knob, will operate push button No. 7632 in box located on case of Signal P-7632.

When red light shows in push button box on Signal P-7632, push button No. 7632 must not be operated until eastward train from Knob is stopped west of Signal P-7260.

Before operating push buttons, carefully review instructions posted in each box.

If signals do not indicate "proceed" in three minutes after push buttons are operated, train may proceed as prescribed by Rule 509(F).

RULE 510. The following block signals equipped with triangular number plate displaying the letter "P" have included in their control limits some special protective device.

Eastward Signal	PROTECTION	Westward Signal
P-3720	Spring switch, end double track, East Santa Barbara	P-3721
P-3722	Spring switch, east end freight lead, Santa Barbara	P-3741
	Spring switch, Ortega	P-3773
P-4086 P-4088	Spring switch, Oxnard	P-4089
P-4170 P-4172	Spring switch, Camarillo	P-4173
	Spring switch, Moorpark	P-4273
	Spring switch, Hasson	P-4411
P-4452	Spring switch, Chatsworth	
P-4880	Spring switch, end double track, Alhambra	P-4881
P-4936	Spring switch El Monte	
	Spring switch, Niland	P-6681
	Spring switch, Knob	P-7231
P-7260 P-7632	Spring switch, Araz Jct.	P-7259 P-7261 P-7263 P-7265

RULE 516. At Flowing Well when holding main track to meet a train, do not open switches until train to be met has passed signal intermediate to next station. When taking siding to meet a train, do not close main track switch until rear of train has passed fouling point or derail.

Overlap posts:
Kaiser—Eastward Trains..............1900 feet east of west switch.
Ailsa—Eastward Trains............300 feet east of west switch.
Colorado—Eastward Trains........Signal 7318.

RULE 535. SPRING SWITCHES

Spring switches equipped with facing point locks are located as follows, and speed indicated must not be exceeded while trailing through the switches:

Location		Normal Position	Maximum Speed Psgr.	Maximum Speed Frt.
East Santa Barbara	End of double track	Westward track	25	20
East Santa Barbara	East end freight lead	Main track	15	15
Ortega	East switch of siding	Main track	15	15
Oxnard	East switch of siding	Main track	15	15
Camarillo	East switch of siding	Main track	15	15
Moorpark	East switch of siding	Main track	15	15
Hasson	East switch of siding	Main track	15	15
Chatsworth	West switch of siding	Main track	15	15
Alhambra	End of double track	Westward track	25	20
El Monte	West switch of siding	Main track	15	15
Niland	East switch of siding	Main track	15	15
Knob	East switch of siding	Main track	15	15
Araz Jct.	End of double track	Eastward track	25	20
Araz Jct.	West switch crossover between main tracks	Eastward track	25	20
Yuma	West end bridge, end double track	Westward track	6	6
Yuma	East end bridge, end double track	Eastward track	6	6

Spring switches not equipped with facing point locks are located as follows, and speed indicated must not be exceeded while passing over the switches in facing movement, or in trailing through them:

Location		Normal Position	Maximum Speed Psgr.	Maximum Speed Frt.
Araz Jct.	Junction switch Inter-Cal Ry.	Eastward track	25	20

RULE 536. Wheels of tenders must not be considered as engine wheels.

RULE 605. INTERLOCKING

BURBANK JUNCTION TOWER

To Mojave Subdivision or Los Angeles, ——.
To Hewitt, —— o o o o.
To siding, o o o o o.
To Industrial lead, o —— o.

Upper unit of three-unit interlocking signal at east interlocking limit on westward main track governs movement on main track to Mojave Subdivision. Center unit governs movement through crossover to Ventura Subdivision. Lower unit governs movement to Valley siding and Coast siding.

Upper unit of two-unit Signal 4714SA at west interlocking limit governs movement to eastward main track. Lower unit governs movement against current of traffic through interlocking limit, and also to General Water Heater spur.

Westward freight trains of over 30 cars must stop before fouling Alameda Ave., Burbank (MP 472.8) unless both arms on Signal 4723 are in proceed position, cutting crossings if blocked by train. Forward brakeman must go to telephone opposite Signal 4724 and communicate with signal operator Burbank Jct. Tower. If signal inoperative and authorized by signal operator to proceed, comply with Rule 509 or 509(F), as the case may be.

GLENDALE TOWER

To or from lead unit "A," o o o o o.

Eastward freight trains held at Glendale Tower, and having Los Feliz Boulevard crossing cut, will, after receiving "Proceed" interlocking signal, couple up the crossing and during coupling operation may expect Glendale Tower to permit traffic, including Pacific Electric cars, to cross the tracks. As soon as train is recoupled and air pumped up, engineer will sound whistle. Glendale towerman will then place interlocking signal in "Proceed" position.

DAYTON AVE. TOWER

To Glendale or East Bank Line, ——.
To River Station Tower or "C" unit, o o o o o.
To Midway unit No. 1 track, o —— o; other tracks or freight lead, —— o ——.
For movement against current of traffic, —— o o o o.

One long blast of tower air whistle requires all movements through plant to stop immediately and remain standing until authorized by signal operator to resume movement.

Special signals on masts of interlocking signals which govern movements from "C" unit, are normally dark, but when displaying flashing yellow light will authorize a train or engine, after stopping, to pass the interlocking signal at stop, and move with caution to the next interlocking signal, expecting to find the block occupied.

RIVER STATION TOWER

To Glendale or Naud Junction, ——.
To Mission Tower or Yard lead, o o o o o.
To tracks one to five inclusive or to "B" shed, except track one, —— o ——.
To tracks six to eleven inclusive, or to track one "B" shed —— o o o o.
To Mission Tower against current of traffic, o o o o ——.

One long blast of tower air whistle requires all movements through plant to stop immediately and remain standing until authorized by signal operator to resume movement.

MISSION TOWER

To LAUPT, o ——.
To Alhambra or Naud Jct., east or west on East Bank Line, ——.
To Roundhouse, —— o —— o.
To River Station Tower or AO spur, o o o o o.
To Brewery spur or Lacy Manufacturing Co., o o o ——.
To Coach yard, o o o o ——.
To Wilson Packing Co. lead, —— o ——.
To or from East Bank Line or Alhambra, o —— o o.
To Alhambra Ave. Coach yard lead, o o —— o.
To Naud Jct. from East Bank Line, o o —— o o.
Against current of traffic, —— o o o o.

Following addition to Rule 663 (b) applies at Mission Tower, "Upon receiving oral authority of signal operator or signal maintainer."

Signs bearing words "Clearing Section" located as follows:

200 ft. west of Signal Bridge No. 3 on the East Bank Line.

200 ft. west of signal on eastward passenger track from East Bank Line to LAUPT via Alhambra Ave.

200 ft. east of first signal east of UPRR Crossing on westward Alhambra Ave. main tracks.

200 ft. east of first signal leaving Coach Yard.

Trains or engines stopped by these signals will stop with head end between "Clearing Section" sign and signal, except, freight trains or switching drags only on East Bank Line will remain west of Main Street when stopped by signal.

One long blast of tower air whistle requires all movements through plant to stop immediately and remain standing until authorized by signal operator to resume movement.

CLEMENT JCT. TOWER

To Butte St. Interchange Yard, —— o ——.

WILMINGTON (ANAHEIM BLVD.) TOWER

Governs crossing AT&SFRy, MP 500.9 San Pedro Branch, also UPRR crossing MP 502.0 and AT&SFRy crossing MP 501.8 Long Beach Branch. Warning signs used instead of distant signals. Telephones at AT&SF and UPRR crossings. Call signal operator to release electric switch lock on Texas Oil Spur, Long Beach branch.

ISLAND JCT. TOWER

Governs crossing of the PERy, located MP 501.9, signals operated from Island Jct. Tower on PERy .34 mile east of crossing.

Eastward home signal 600 feet west of crossing. Westward home signal 580 feet east of crossing.

Consolidated Rock Company spur switch 50 feet west and Consolidated Lumber Company spur switch 200 feet east of crossing protected with electric switch locks. For movement into these spurs receive signal indication from home signals to proceed over crossing and after passing home signal electric locks will be unlocked.

To use locks open door, throw lever to the left, then throw switch and restore electric lock lever to normal and close and lock door.

For movement out of either spur call signal operator at Island Jct. Tower from telephone at crossing.

When using these spurs clear the main track as soon as possible to avoid delay to PERy and SP trains.

ANAHEIM TOWER

Signal operator on duty 2.30 p. m. to 6.30 p. m. and 7.30 p. m. to 11.30 p. m. daily except Sunday. Plant cannot be operated by member of crew.

EL MONTE TOWER

To or from siding, o o o o o.

POMONA JCT. TOWER

To Packing House track, —— o o o o.

POMONA

Limits extend from Signal 5124SA to Signal 5125SA on main track and to Signal 5127SA on siding. If necessary to hand-throw switch to siding, first secure authority by telephone from operator, obtain crank from box on side of concrete house. Insert crank in switch-machine at opening locked by switch lock, turn crank until switch is thrown. After use, restore switch to position in which found, and restore crank to box.

Eastward trains except first-class, finding Signal 5124SA displaying proceed indication for main track are thereby given superiority over all opposing trains except first-class, to fouling point of crossover east of station building. First-class trains will be governed by their time-table or train-order authority.

COLTON TOWER

To No. 2 track, ——— o ———.
To Riverside, o o ——— o.
To Santa Fe interchange, o o o o o.

SAUGUS

Switch at east end westward siding Saugus and switch at west end Newhall siding are interlocked and controlled from train-order office Saugus. All other switches are normally operated.

Interlocking limits extend from point on main track 265 feet west of east switch westward siding, Saugus, to point on main track 265 feet east of west switch, Newhall.

Automatic Light Type Signal 4523 has the letter "M" indicator and green light indicator mounted on the mast. The letter "M" displayed, authorizes a movement to continue on main track to the Saugus telegraph office, but must be governed by indications of Automatic and Semi-automatic Signals.

AUTOMATIC INTERLOCKING

When signal governing use of automatic interlocking indicates "Stop" and no cause to be seen, or, if a standing train is seen on intersecting tracks with no indication that they are to proceed, flagman must be sent ahead immediately to open box at crossing and comply with rules posted therein.

After release has been operated by flagman, signal should change to "proceed", or a red indicator light appear at interlocking signal. If red indicator light appears, train may proceed over crossing. If red indicator light does not appear, movement over crossing must be protected in each direction on intersecting tracks. Instructions in box indicate the time interval required for release to function.

SAN PEDRO LINE

NADEAU INTERLOCKING

Crossing AT&SFRy, 0.9 mile east of Vernondale.

SANTA ANA BRANCH

SOUTHGATE INTERLOCKING

Crossing UPRR.

RIVERSIDE BRANCH

HIGHGROVE INTERLOCKING

Crossing AT&SFRy, 0.7 mile east of Orange Center.

SPECIAL SIGNALS

Riverside Branch between MP 540.085 and MP 545.914 used jointly by SP and PERy without train orders.

Light type special signals for eastward movement at fouling point PERy junction switch Colton, and 15 feet east of east switch Highgrove; and for westward movement 800 feet west of Riverside Jct. and 15 feet east of east switch Highgrove confer authority to the next special signal, except that the signals at Highgrove confer authority to the limit of these signals; and their indications supersede the superiority of trains for both opposing and following movements, but do not dispense with the use or observance of other signals.

Trains must stop before reaching signals, and comply with instructions posted in cut-in and cut-out boxes adjacent to signals for operation of toggle switches to clear signals.

If signal cannot be cleared, wait five minutes, then send flagman ahead, wait five minutes more, then follow flagman through block, moving with caution, not exceeding 12 MPH.

Toggle switch in cut-out box must be operated after rear of train passes 50 feet beyond signals.

RULE 740. ABSOLUTE-PERMISSIVE BLOCK SYSTEM

MP 459.9-NORTH HOLLYWOOD

Absolute-Permissive Block System between MP 459.9 and North Hollywood, Burbank Branch.

YUMA-COLORADO

Limits extend from absolute signals west of Colorado River bridge to absolute signals east of Colorado River bridge. Speed must not exceed 6 MPH until engine has passed spring switch at opposite end of bridge.

Trains stopped by absolute signal west of bridge must obtain permission from yardmaster, and also make inspection of spring switches at each end of bridge before proceeding.

RULE 760. CENTRALIZED TRAFFIC CONTROL SYSTEM

Limits extend from MP 539.79 Colton, to MP 610.6 Indio.

Switch at MP 610.3 Indio is dual control switch, but turnout track is not a controlled siding.

Call-on lights on absolute signals at crossovers Loma Linda and Beaumont, when flashing yellow authorize movement on siding, after stopping, expecting to find siding occupied.

Trains receiving clearance at Colton, Indio or Indio Yard are thereby authorized as indicated on clearance, without train-order authority, to the beginning of C.T.C., being governed by block signalswhose indications will supersede the superiority of trains. Clearance for a section must read "no signals" or "green signals" following the address.

Trains also are authorized from C.T.C. limits to Indio, Indio Yard, or Colton without train-order authority, being governed by block signals whose indications will supersede the superiority of trains.

All movements between C.T.C. limits and Colton, Indio or Indio Yard must be made with caution, not exceeding 20 MPH.

Eastward trains must not pass fouling point of east switch of PFE lead Colton, unless proceed signal received from yardman (green flag by day, green light by night).

West switch balloon track Colton is spring switch without facing point lock.

Instructions for operating dual control switches by hand posted in phone booths.

Instructions for operating switches equipped with electric locks controlled by dispatcher posted on inside of lock-box doors.

RULE 763. Revised to read as follows:

Train indicators, signals and markers must be displayed through centralized traffic control limits. Rule S-17, Fig. 7 of Rule 19, and Rule 19 (A) will not apply on controlled sidings.

RULE 775. When helpers are cut out of rear end of trains on controlled siding Beaumont, a reverse movement by helpers may be made without permission from dispatcher.

Before moving from controlled siding to engine track from the west at Beaumont, permission from dispatcher must be obtained.

RULE 776. When helper is cut off of head end of westward train on main track Beaumont, train may follow helper, but must move with caution until track is known to be clear to next absolute signal.

RULE 825. When necessary to cut crossing and a distance of 100 feet on each side cannot be provided, a flagman must protect. Cars must not be left in any position that would in any way intercept the view of an autoist or pedestrian of an approaching train, unless crossing is protected as stated above.

Cars must not be left standing on tracks within 100 feet of the following intersections at Burbank: Burbank Boulevard, Magnolia Ave., Olive Ave., Verdugo Ave., Alameda Ave., except cars may be spotted for service at Libby, McNeill & Libby Plant, S. E. corner of Verdugo Ave. and S. P. tracks; Andrew Jergens Soap Co., S. W. corner of Verdugo Ave. and S. P. tracks; Hudson-Bonney Lumber Co., N. E. corner Alameda Ave. and S. P. tracks; on Team Track, most northerly track crossing Olive Avenue.

When cars are left on grade not protected withderails they must be chained to rail.

Santa Barbara—Cars placed on passenger station house track must be protected with skid. When skids are not in use they must be returned to proper location.

North Hollywood—House track east of derail must not be used.

RULE 828. Rolling inspection must be made on eastward freight trains at Santa Susana and on westward freight trains at Northridge. Unless trains stop at either of the two points for operating purposes, trains must reduce speed sufficiently to permit rolling inspection.

RULE 833. Whenever practicable locomotive cranes, or cranes of similar types must be handled in trains with heavy end forward.

Except those of Southern Pacific ownership, cranes or machines of similar type, with rotating body, loaded on open cars, must not be moved until inspected and released by mechanical department. Conductors must not move Jordan Spreaders, except when in use, unless wings are protected against spreading by chain or tie bar extending from wing to wing and wing arm to wing arm.

RULE 836. Cars moved from one station to another ahead of engine on descending grade must be chained to the engine. Switching movement on descending grades must be protected by a derail. When practicable engine must be kept on lower end of cars.

When necessary to move cars ahead of engine do not exceed 20 MPH.

RULE 837. Fifth paragraph is revised to read as follows:

Cars standing on grade must not be coupled onto, in descending direction, without knowing sufficient hand brakes are set to prevent uncontrolled movement of any such cars should coupling fail or cars not be securely coupled together.

RULE 849. Steam valve on Pullman troop sleepers cannot be opened while train is in motion, and when such car is on rear of train steam line must not be cut in any portion of train until valve is closed on the car on each side of coupling to be opened, to avoid burning by steam.

RULE 869. All brakemen except rear brakeman must ride on top of train as follows:

Beaumont to Edom
Beaumont to Colton

Trainmen must remain with their portion of train until it stops on designated track in yards.

Fourth or additional brakemen must ride near middle of portion of train assigned to them.

Trainmen must not ride on top of train while passing through Tunnel 26 between Hasson and Chatsworth.

RULE 883. Engines must not be left standing unattended on any track where there is a possiblity of their fouling the main track without being secured by a derailer. If no derail in the track on which engine is left standing, the engine must be secured by blocking or by leaving engine coupled to cars on which hand brakes are properly applied.

RULE 827. TRAIN INSPECTION

Trains, including military trains, made up in part of freight cars or caboose equipped with cast iron wheels, are required to comply with rules and time-table instructions applying to freight trains as they relate to stopping for train inspection, and speed restrictions.

When practicable, trainman must ride rear platform or in rear car on all trains, in position, where he can observe fire that might be set from moving train, when passing through wooden lined tunnels and over long, open-deck wood trestles.

Cars bearing placards denoting contents are explosive, inflammable, poisonous, or otherwise dangerous, must be given careful inspection at all points where train inspection is made.

Eastward freight trains must stop 10 minutes at Cabazon and Garnet and westward 10 minutes at El Casco or Ordway for inspection. Exceptions: If required to stop at any station Owl to Garnet inclusive, inspection will be made, and subsequent run for inspection must not exceed 14 miles. Westward freight trains if required to stop at Hinda, inspection may be made at Hinda and Redlands instead of El Casco or Ordway.

Westward freight trains on main track or siding, Beaumont, regardless of signal indications, will stop before reaching westward absolute signals located on signal bridge east of California Street.

While brake system is being recharged, trainmen will commence turning up retainers, and as soon as brake system has been recharged, train will proceed to west end to cut out helpers, and, if necessary, complete turning up required number of retainers.

When an eastward train is delayed to exceed 25 minutes at an inspection point, subsequent run for inspection must not exceed 10 miles.

Engines running light on descending grade must stop at freight train inspection points a sufficient length of time for engineer to satisfy himself that tires and machinery are in satisfactory condition. Between Yuma and Niland, when conditions are favorable, and in the judgment of the conductor and engineer it is safe to do so, freight trains in either direction need not stop for inspection.

On freight trains moving on all branches except San Pedro, Long Beach, Santa Ana and Sandia, a member of train crew must ride on rear platform of caboose to observe any condition requiring an immediate stop of the train.

Passenger trains making station stop at Santa Barbara, Oxnard, Colton, Indio and Niland will approach at not to exceed 8 MPH to allow forward brakeman to get off where rear of train will stop. He will then make rolling inspection, then walk length of train opposite station side making standing inspection, giving careful attention to running gear and journal boxes.

At Santa Barbara, brakemen called for eastward extra sections of passenger trains and extra passenger trains will station themselves to make rolling inspection both sides of train as train arrives. Forward brakeman then walk forward on station side making standing inspection.

AIR BRAKE RULES

RULE 17. On freight trains 125 M's per operative brake must not be exceeded on descending grade between Colton and Garnet.

One retaining valve for each 120 M's, commencing at forward end of train must be turned up Beaumont to Edom. Retaining valves may be turned down at Rimlon if train stops for other operating reasons and not required beyond in judgment of engineer.

One retaining valve must be turned up for each 140 M's Beaumont to Redlands; exception:

One retaining valve must be turned up for each 120 M's on westward freight trains consisting of 50 or more loaded tank cars, or 20 or more cars of beets, between Beaumont and MP 540.

One retaining valve must be turned up for each 200 M's, Redlands to MP 540.

One retaining valve must be turned up for each 100 M's in westward trains of over 10 cars on Pasadena and Redlands branches.

One retaining valve must be turned up for each 150 M's on eastward trains handling 20 or more cars of rock or sand, Roscoe to Los Angeles Yard, and continuous run may be made between these points. If stop made between Burbank Jct. and Los Angeles Yard for other operating reasons, retaining valves may be turned down if not required beyond.

On eastward passenger trains all retaining valve handles must be turned up at Beaumont or Apex, and stop must be made at Garnet where handles will be turned down, except if stop is to be made at Palm Springs handles on head end cars may be turned down at that point provided not less than 75% of cars in train have handles turned up.

On westward passenger trains all retaining valve handles must be turned up at Beaumont, and must be turned down on passenger carrying cars at Loma Linda, and must be turned down on head end cars at Colton.

When overheating is apparent handles may be turned down on such cars.

FREIGHT TRAINS

RULE 25. Beaumont: Rear end test must be made except running test may be made by westward trains of not over 65 cars immediately after leading engine passes MP 563.60 and, if brakes operate properly, stop for rear end test not required.

Before a train which has stopped on grade is signalled to proceed, air gage in caboose must be observed. If gage indicates brake pipe unobstructed and registers a pressure of not less than 65 pounds, proceed signal may be given.

PASSENGER TRAINS

RULE 36. Car inspectors at Los Angeles and Yuma will furnish passenger conductors and engineers a written check of the number, type, percentage of graduated release, and condition of air brake equipment in their train. Conductor will give this information to road and helper engines coupled to his train en route, delivering a written check to relieving conductor.

RULE 38. Exception: At Santa Barbara, engineers will use hand, instead of steam whistle, signals. Trainmen will place themselves in a position to relay signals to the best advantage.

RULE 39. Running test must be made before descending grade, Beaumont.

Running test must be made on eastward trains three miles west of Burbank Jct.

Running test need not be made approaching Glendale Tower.

Running test of trains leaving LAUPT must be made immediately after clearing Mission Tower interlocking.

If air brakes have been used at Alhambra, running test need not be made approaching Mission Tower.

MISCELLANEOUS

1. Westward trains take only sufficient water at Amos to insure making run to Niland, and only sufficient water at Mecca to make Indio.

Eastward trains take only sufficient water at Pomona to insure making Colton.

Eastward freight trains take water at Calexico from column opposite roundhouse, unless otherwise instructed.

Trains stopped at Calexico will avoid blocking connection between wye and east end roundhouse lead.

Eastward freight trains taking water at Santa Paula stop west of Tenth St. (at station) and cut engine off to take water.

4. Helper service:

No helper engine will be placed behind wooden underframe cars or cabooses.

Engines weighing more than 235,000 pounds on drivers will not be placed behind steel underframe cabooses.

In no case will more than one helper engine be placed behind steel underframe cabooses.

One helper may be placed on head end, but not more than two engines will be used on head end of any freight train. When additional helpers are required, they will be placed back in train and cut in ahead of any cars of wooden frame construction.

Air will be cut in on all helper engines, and engine must not be cut off when train is in motion.

When used as helpers in rear of train, AC, AM or MM class engines must not be coupled together, nor may more than two F, Mt, or heavier class, or more than three smaller classes be coupled together. When coupled, larger engines must be placed ahead of smaller engines. If tonnage requires more power, additional helpers of not to exceed two coupled in each case, must be separated by at least four cars.

Helpers must not be operated backing except in emergency, and in such case engines should not push through a backing engine if it can be avoided.

Helper engines coupled in middle or rear of train must be cut off from forward portion before taking water. On grades road engine and helper must not be cut off from train at the same time without hand brakes being securely set.

Helper engines on freight trains must be placed in rear through Tunnel 26.

4 (a). For the purpose of pushing trains out of yards:

No engine will be placed behind wooden underframe caboose or other wooden frame equipment.

Engines weighing more than 235,000 pounds on the drivers will not be placed behind steel underframe cabooses except eastward freight trains at Beaumont.

Air will not be coupled through pusher engine.

Yard engines regularly so used will be equipped with Russell-Jordan device to hold the coupler pin from dropping, thus making it unnecessary for employes to uncouple the pusher engine when cutting off.

In no case shall the knuckle be removed, or closed, or cutting lever temporarily fastened in release position on a pusher engine, as means of preventing coupling being made.

Unless local conditions require, it will not be necessary to stop trains to detach pusher engines.

7. Capacity of sidings between clearance points is based on an average car length of 49 feet not including engines and caboose.

Figures between station names on schedule pages indicate distance from initial switch of siding at one station to initial switch of siding at next station. If no siding it is distance to points where time applies.

10. High water may be anticipated at Bridge 427-B, one-half mile west of Cavin, Santa Paula Branch. Approach this structure with caution, looking out for obstructions on track, and stopping if necessary to make an examination before passing.

Engines equipped with pilot snow plow, except Mt and GS class, are prohibited from entering Los Angeles Union Passenger Terminal account impaired platform clearance.

Take necessary precautions when sand blowing between signs reading "Sand" at following points:

MP 522.4 west of Guasti to MP 528.38 west of South Fontana;
MP 588.25 east of Garnet to MP 596.5 east of Rimlon;
MP 679.4 to MP 681.5 east of Tortuga;
MP 698.9 to MP 700.4 east of Glamis;
MP 701.6 west of Ruthven to MP 703.85 east of Ruthven.

AC 1, 2 and 3 class engines may be used on Pasadena Branch.

All classes may be used on Burbank Branch from west end at Chatsworth to a point 1000 feet east.

AC class engines may use Ojai Branch between Ventura Jct. and Main St. MP 398.00 including Hobson and water spurs.

Engines heavier than C class must not be doubleheaded on Santa Paula Branch.

Engines heavier than C class must not be used on tracks at points listed below:

Santa Barbara	In old yard; Caboose; Swamp; team behind freight house. Must not back up through short crossovers at west end freight yard.
Summerland	House track and oil spur.
Ortega	Oil spur.
Carpinteria	Outfit spur; MOD spur east of road crossing.
Seacliff	Team, 200 feet beyond clearance point.
Ventura Jct.	Associated Oil spur.
Ventura	Wholesale Grocery.
Oxnard	Tracks in the yard of the American Crystal Sugar Company beyond following points: Tracks 1 and 2—opposite scale house. Track 7—First switch at scale house. Tracks 8 and 9—175 feet beyond switch between such tracks. Tracks 18 and 19—One engine length beyond first crossover between such tracks. Tracks 20, 21 and 22—Also, no SP engine permitted to use crossover between tracks 19 and 20. Road crossing 1870 feet east of west switch track 20 must be kept clear.
Leesdale	Team beyond clearance point.
Strathearn	Corral beyond a point 380 feet from switch point.
Simi	Spur.
Santa Susana	Tapo spur; Corral.
Chatsworth	Storage; Beyond a point 600 feet from switch. Stem of wye beyond a point 200 feet from wye switch.
San Pedro	High line.
Rudell	Spur.
Pomona	Back team track west of Main St. Winery spur.
Ontario	Assets Corporation.
South Fontana	Quarry tracks.
Beaumont	West end oil unloading track, Blinn Lumber spur.
Rockwood	All except main track.
Brawley, El Centro, Calexico	Icing tracks or leads.
El Centro	Old wye.
Between Niland and Calexico	Industry tracks, exclusive of drill track at Calipatria.
Between Indio and Yuma	Spurs; except Standard Oil, Narborn, Coachella Valley Grape Growers, ice house at Coachella; Mortmar, Durmid, Pope, Wister, Glamis, Acolita and Ogilby.
Mecca	Water track beyond 100 feet east of crossing.
Iris	House track.
Knob	House track.

AC-10 class engines must not enter curve on fruit packer's spur at west end of house track at Beaumont. If necessary to pick up off this spur, reach must be used.

Engines must not use American Crystal Sugar track 3, Oxnard.

Engines heavier than 200,000 pounds on drivers must not be used on San Gabriel Valley Lumber spur at San Gabriel beyond clearance point, or tracks of South Fontana Farm Co., South Fontana.

20. Handling of freight cars in trains behind passenger cars is prohibited except passenger equipment may be placed in head end of mixed trains when carrying personnel and equipment in connection with military and naval movements. This does not refer to a baggage, express, or mail car, or a caboose.

All cars moved in passenger trains must be equipped with steel-tired or all-steel wheels. When cars not so equipped are offered for movement, they will be handled in freight trains—passengers, if any, to move on passenger train.

Wooden passenger-carrying cars, wooden baggage, express and other head-end cars, unless equipped with steel center sills and steel platforms, must not be used in passenger service.

Not more than 30 express refrigerator cars may be handled in one freight train and such equipment must be in rear of train.

23. Trains and engines moving on Alameda Street, Los Angeles, must respect city traffic signals, when in operation.

29. Movements over Union Pacific tracks between Santa Fe overhead bridge 2606 feet east of Dayton Ave. Tower (East Bank line) and connection switch Butte St. yard at Santa Fe Ave. 3550 feet west of Butte St. Jct., are governed by Union Pacific rules, time tables, special instructions, and bulletins.

Trainmen and enginemen operating over East Bank line of the Union Pacific Railroad must provide themselves with copy of Union Pacific Special Rules, and pamphlet indicating points of difference between Union Pacific and Southern Pacific operating rules, which may be secured at crew dispatchers' office Taylor yard and roundhouse; roundhouse foreman's office Alhambra Ave., and train order office LAUPT.

LOCATION OF OVERHEAD AND SIDE STRUCTURES NOT STANDARD CLEARANCE

Mile Post	BETWEEN	HEIGHT	DESCRIPTION
441.2	Hasson and Chatsworth	20 ft. 2 in.	Tunnel No. 26.
442.9	Hasson and Chatsworth	20 ft. 6 in.	Tunnel No. 27.
443.9	Hasson and Chatsworth	20 ft. 6¾ in.	Tunnel No. 28.
423.0	Sespe and Fillmore	21 ft. 4 in.	Sespe Creek Br.
432.2	Piru and Camulos	21 ft. 4 in.	Piru Creek Br.
481.7	L. A. Yard—River Sta. Tower	21 ft. 6 in.	Footbridge.
547.3	Motor Jct.-Redlands 2d St.	19 ft. 6 in.	Mill Creek Br.

Open deck trestle at MP 462.44, 90 feet west of east switch of joint track North Hollywood; 90 feet east of east switch at east end of joint track at MP 459.9; MP 540.11 Santa Ana River Bridge Riverside Branch.

Pacific Electric trolley poles on Riverside Branch between MP 539.43 and MP 541.36; and on Covina Branch between Lone Hill and Ganesha Jct., will not clear man on side of car.

Following water tanks are not standard clearance: Santa Paula, Pomona, Guasti.

Employes are warned that it is dangerous to ride on top or sides of cars while passing these points and that they must protect themselves from injury.

There are numerous structures with impaired clearance on yard and station tracks on the division, and employes must be familiar with their locations and avoid personal injury.

HOSPITALS

General Hospital—San Francisco, Cal.
Division Hospital—White Memorial Hospital, Los Angeles, Cal.
Emergency Hospital, General Shop Yard, East Los Angeles, Cal.
Emergency Hospital, Taylor Yards, Los Angeles, Cal.
Emergency Hospital, Colton, Cal.
Emergency Hospital, Indio, Cal.

SURGEONS

LOCATION	NAME	TITLE
San Francisco		Chief Surgeon
Los Angeles	Dr. M. T. Steele	Assistant to Chief Surgeon
Los Angeles	Dr. R. W. Starr	Division Surgeon
Los Angeles	Dr. A. S. Lineer	District Physician and Surgeon
Los Angeles	Dr. R. R. Holzman	District Physician and Surgeon
Los Angeles	Dr. W. P. Thearle	District Physician and Surgeon
Los Angeles	Dr. J. W. Schaefer	District Physician and Surgeon
Los Angeles	Dr. M. A. Heffelfinger	District Physician and Surgeon
Los Angeles	Dr. J. W. Nielson	District Physician and Surgeon
Los Angeles	Dr. Oliver K. Malcolmson	District Physician and Surgeon
Los Angeles	Dr. James F. Presnell	District Physician and Surgeon
Los Angeles	Dr. Philip R. Fulton	District Physician and Surgeon
Los Angeles	Dr. John J. Mandel	Emergency Surgeon
Los Angeles	Dr. Harry Brodsky	Assistant Surgeon
Los Angeles	Dr. Loren Vixie	Visiting Physician
Los Angeles	Dr. G. T. Thomason	Visiting Physician
Los Angeles	Dr. Jacob Janzen	Visiting Surgeon
Los Angeles	Dr. R. A. Woodhull	Oculist and Aurist
Los Angeles	Dr. Jos. Goldstein	Oculist and Aurist
Los Angeles	Dr. Richard F. Mogan	Asst. Oculist and Aurist
Los Angeles:		
Angelus-Mesa	Dr. F. X. McDonald	District Physician and Surgeon
Inglewood-Hyde Park	Dr. E. D. Charland	District Physician and Surgeon
Huntington Park	Dr. H. W. Amyes	District Physician and Surgeon
Eagle Rock	Dr. A. E. Hollenbeck	District Physician and Surgeon
Hollywood	Dr. R. W. Avery	District Physician and Surgeon
North Hollywood	Dr. T. H. Ransom	District Physician and Surgeon
Wilshire-Beverly Hills	Dr. Peter J. Scherr	District Physician and Surgeon
F. R. Strong Bldg., 7th and Central	Dr. M. H. Burge Dr. J. R. Martin	District Physician and Surgeon District Physician and Surgeon
Watts	Dr. Fred L. Scott	Emergency Surgeon
Santa Monica	Dr. L. E. Croft	District Physician and Surgeon
Compton	Dr. Ernest I. Mulder	District Physician and Surgeon
Long Beach	Dr. C. H. Woods	Emergency Surgeon
Long Beach	Dr. William C. Clough	Emergency Surgeon
Wilmington	Dr. W. W. Horst	District Physician and Surgeon
Wilmington	Dr. A. H. Nerad	Asst. Dist. Physician and Surgeon
San Pedro	Dr. J. L. Bloch	District Physician and Surgeon
Downey	Dr. R. V. Fernandez	Emergency Surgeon
Whittier	Dr. J. W. Camp	Emergency Surgeon
Norwalk	Dr. L. J. Otis	District Physician and Surgeon
Anaheim	Dr. J. L. Beebe	District Physician and Surgeon
Orange	Dr. Arthur J. Nies	Emergency Surgeon
Santa Ana	Dr. Dexter R. Ball	District Physician and Surgeon
Santa Ana	Dr. John D. Ball	Asst. Dist. Physician and Surgeon
Westminster	Dr. R. I. Johnson	Emergency Surgeon
Pasadena	Dr. Z. T. Malaby	District Physician and Surgeon
Pasadena	Dr. Jos. A. Walshe	District Physician and Surgeon
Monrovia	Dr. E. H. Kelly	Emergency Surgeon
Alhambra	Dr. J. F. Hull	District Physician and Surgeon
San Gabriel	Dr. C. L. Magee	Emergency Surgeon
El Monte	Dr. E. D. Farrington	District Physician and Surgeon
Puente	Dr. W. W. Schultz	District Physician and Surgeon
San Dimas	Dr. S. Thomason	Emergency Surgeon
Covina	Dr. G. H. Ernsberger	Emergency Surgeon
Pomona	Dr. Geo. W. Keller	District Physician and Surgeon
Pomona	Dr. S. D. Carney	District Physician and Surgeon
Chino	Dr. H. R. Miller	District Physician and Surgeon
Colton	Dr. C. F. Whitmer	District Physician and Surgeon
Colton	Dr. J. N. Martin	Asst. Dist. Physician and Surgeon
San Bernardino	Dr. James S. Forsythe	District Physician and Surgeon
San Bernardino	Dr. C. M. Hadley	Oculist and Aurist
Riverside	Dr. Thomas A. Card	District Physician and Surgeon
Redlands	Dr. H. G. Hill	District Physician and Surgeon
Banning	Dr. A. L. Bramkamp	District Physician and Surgeon
Beaumont	Dr. F. D. West	District Physician and Surgeon
Indio	Dr. W. H. Blackman	District Physician and Surgeon
Indio	Dr. M. A. Lauter	Asso. Dist. Physician and Surgeon
Indio	Dr. M. J. Pierce	Oculist and Aurist
Westmorland	Dr. O. C. Long	Emergency Surgeon
Brawley	Dr. A. H. Foster	Asso. Dist. Physician and Surgeon
Brawley	Dr. John L. Parker	Asso. Dist. Physician and Surgeon
Imperial	Dr. H. V. Gray	District Physician and Surgeon
El Centro	Dr. F. W. Peterson	District Physician and Surgeon
El Centro	Dr. W. W. Apple	District Physician and Surgeon
Holtville	Dr. H. B. Graeser	District Physician and Surgeon
Calexico	Dr. T. E. Bartholomew	District Physician and Surgeon
Mexicali	Dr. Mario Flores	District Physician and Surgeon
Mexicali	Dr. Gaston H. Salazar	Asst. Dist. Physician and Surgeon
Yuma	Dr. W. A. Phillips	District Physician and Surgeon
Yuma	Dr. W. C. Cain	Asst. Dist. Physician and Surgeon
Glendale	Dr. Chester L. Roberts	District Physician and Surgeon
Burbank	Dr. David Thomson	District Physician and Surgeon
Van Nuys	Dr. Chas. B. Canby	Emergency Surgeon
Canoga Park	Dr. Wm. J. Lakey	Emergency Surgeon
Fillmore	Dr. H. B. Osborn	District Physician and Surgeon
Santa Paula	Dr. D. G. Clark	District Physician and Surgeon
Saticoy	Dr. C. R. Illick	Emergency Surgeon
Moorpark	Dr. F. A. Yoakam	Emergency Surgeon
Oxnard	Dr. Arthur H. Stoll	District Physician and Surgeon
Ventura	Dr. Fred A. Shore	District Physician and Surgeon
Ojai	Dr. C. G. Drace	Emergency Surgeon
Carpinteria	Dr. T. M. Shorkley	Emergency Surgeon
Santa Barbara	Dr. Chas. S. Stevens	District Physician and Surgeon
Santa Barbara	Dr. Kenneth Jennings	District Physician and Surgeon
Santa Barbara	Dr. Alfred B. Wilcox	Asst. Dist. Physician and Surgeon
Santa Barbara	Dr. A. B. Steele	Asst. Dist. Physician and Surgeon
Santa Barbara	Dr. Wm. J. Mellinger	Aurist
Santa Barbara	Dr. W. H. Johnston	Oculist
Santa Barbara	Dr. W. B. Gibb	Oculist

Note.—Emergency surgeons should only be summoned for temporary treatment when prompt attention is required and when patients cannot be sent to or await arrival of Division or District Surgeon.

AVERAGE TARE WEIGHTS OF PASSENGER TRAIN CARS

	CLASS	NOT AIR-CONDITIONED		AIR-CONDITIONED	
		All-Steel	Steel Underframe	All-Steel Cooling Season	All-Steel Heating Season
	Box-Baggage—40 ft. 6 in.	48,165			
	Baggage—60 ft.	95,188	79,990		
	" —61 ft.		90,478		
	" —66 ft.	129,018	107,727		
	" —70 ft.	125,676			
	Baggage & Mail—60 ft.	111,204			
	" " " —66 ft.	135,460	119,220		
	" " " —69 ft.	128,017			
	" " " —70 ft.	131,100			
	Baggage & Passenger—60 ft.	102,015			
	" " " —61 ft.		115,200		
	Baggage—Horse—70 ft.	133,275			
	" " —80 ft.	150,265			
	Postal—40 ft.	83,467			
	" —60 ft.	118,466			
	Postal Storage—60 ft.	108,335			
	" " —61 ft.	121,210			
	Express Refr.—P.F.E. Nos. 500 to 799		83,200		
	Club (ACI)			165,233	159,233
	Official	158,046	158,182		
	" (ACW)			191,108 121,160	191,108 121,160*
	" (ACE)			172,200 142,800	172,200 142,800*
	Chair—60 ft.	105,206			
	" —60 ft. (ACI)			140,150	134,150
	" —72 ft. (ACI)			163,323	157,323
	" —72 ft. (ACW)			159,639	159,639
	" —73 ft. (ACI)			155,133	149,133
	" —74 ft. (ACI)			179,383	173,383
	" —74 ft. (ACW)			170,087	170,087
	" —74 ft. (ACS)			196,908	180,908
	Coach—60 ft.	100,304			
	" —60 ft. (ACI)			134,334	128,334
	" —70 ft. (ACI)			156,925	150,925
	" —70 ft. (ACW)			152,450	152,450
	" —72 ft. (ACI)			161,464	155,464
	" —72 ft. (ACW)			158,708	158,708
	" —74 ft. (ACI)			174,840	168,540
	" —72 ft. (Suburban)	120,243			
	All-Day Lunch—60 ft.	102,171			
	" " " —60 ft. (ACI)			125,250	119,250
	Cafe-Lounge—70 ft. (ACI)			171,300 181,400	165,300 175,400*
Light Weight Equipment	Chair-Baggage (ACS)			127,000	111,000
	Chair (ACW)			120,000	120,000
	" (ACS)			127,000	111,000
	" —Articulated (ACS)			208,000	176,000
	" — " (ACW)			198,000	198,000
	Diner (ACS)			129,000	113,000
	" —Triplex (ACS)			349,000	301,000
	" — " (ACW)			299,000	299,000
	" — " (Lark) (ACW)			305,000	305,000
	Tavern (ACS)			162,000	114,000
	Parlor (ACS)			130,000	114,000
	Parlor-Observation (ACS)			123,000	107,000
	" " (ACW)			115,000	115,000
	Diner—73 ft.	158,113			
	" —77 ft. (ACM)			199,714	183,714
	" —77 ft. (ACW)			169,369	169,369
	" —77 ft. (ACI)			183,217	177,217
	" —79 ft. (ACW)			176,480	176,480
	" —80 ft. (ACM)			210,340	194,340
	Lounge—75 ft. (ACW)			159,476	159,476
	" —75 ft. (ACI)			170,786	164,786
	" —80 ft. (ACW)			185,333	185,333
	" —80 ft. (ACI)			190,870	184,870
	Observation-Lounge—77 ft. (ACW)			187,053	187,053
	Observation-Smoking—73 ft.		156,080		
	" " —75 ft.	156,000			
	" " —75 ft. (ACI)			166,100	160,100
	Pullman—Sleeper (ACM)			193,985	177,985
	" — " (ACI)			182,350	176,350
	" —Tourist (ACM)			191,076	175,076
	" — "	159,329			
	Pullman—(lightweight) (ACW)			133,600	133,600
	" —(") (ACM)			140,530	124,530
	Pullman—Troop Sleeper	75,250			
	" — " Kitchen	78,920			
	USA—Kitchen	80,800			
	" —Ward (ACI)			179,300	173,300
	" — " (ACM)			173,400	157,400
	" —Dressing (ACI)			171,700	165,700
	" —Hospital—(Cars 89200-89201) (ACI)			168,100	162,100
	" — " (Cars 89340 to 89352) (ACI)			156,600	150,600

*Steel Underframe.

CODE:—
NAC—Non-Air-Conditioned.
ACI—Air-Conditioned—Ice System.
ACM—Air-Conditioned—Mechanical System.
ACW—Air-Conditioned—Waukesha System.
ACS—Air-Conditioned—Steam Ejector System.
ACE—Air-Conditioned—Evaporative System.

SPEED TABLE

SPEED PER HOUR	1 MILE IN MINUTES SECONDS	SPEED PER HOUR	1 MILE IN MINUTES SECONDS	SPEED PER HOUR	1 MILE IN MINUTES SECONDS	SPEED PER HOUR	1 MILE IN MINUTES SECONDS	SPEED PER HOUR	1 MILE IN MIN. SEC.
6	10.00	24	2.30	37	1.37	50	1.12	63	0.57
8	7.30	25	2.24	38	1.34	51	1.10	64	0.56
10	6.00	26	2.18	39	1.33	52	1.09	65	0.55
12	5.00	27	2.13	40	1.30	53	1.08	67	0.54
15	4.00	28	2.08	41	1.27	54	1.06	68	0.53
16	3.45	29	2.04	42	1.25	55	1.05	69	0.52
17	3.31	30	2.00	43	1.23	56	1.04	70	0.51
18	3.20	31	1.56	44	1.21	57	1.03	72	0.50
19	3.09	32	1.52	45	1.20	58	1.02	74	0.49
20	3.00	33	1.49	46	1.18	59	1.01	75	0.48
21	2.51	34	1.45	47	1.16	60	1.00		
22	2.43	35	1.42	48	1.15	61	0.59		
23	2.36	36	1.40	49	1.13	62	0.58		

DIVISION MILEAGE

Main Lines

Saugus to Yuma	S. P. R. R.		281.35		
Santa Barbara to Burbank	S. P. R. R.		93.45		
Niland to Calexico	S. P. Co.		41.70		
Cantu to Araz Jct	S. P. Co.		2.71		
Total Main Lines					419.21

Branches

Burbank	S. P. R. R.	Burbank to Chatsworth Junction		20.74	
Chino	S. P. R. R.	Pomona to Chino		5.06	
Covina	S. P. R. R.	Bassett to Pomona		17.40	
Declezville	S. P. R. R.	South Fontana to Declezville		1.65	
Long Beach	S. P. R. R.	Wilmington (Anaheim Blvd.) to Long Beach		2.31	
Los Alamitos	S. P. R. R.	West Anaheim to Los Alamitos		9.60	
Smeltzer	S. P. R. R.	Stanton Jct. to Wintersburg		6.68	
Ojai	S. P. R. R.	Ventura Jct. to Ojai		15.13	
Pasadena	S. P. R. R.	Alhambra to Pasadena		4.69	
Redlands	S. P. R. R.	Bryn Mawr to Crafton		7.14	
Riverside	S. P. R. R.	Colton to Riverside		8.59	
Sandia	S. P. Co.	Calipatria to Near Holtville	27.46		
	H. I. Ry.	Near Holtville to El Centro	9.73	37.19	
San Pedro	S. P. R. R.	Firestone Park to San Pedro	17.97		
	L.A.&S.L.R.R.	At Los Angeles	7.30		
	P. E. Ry.	At San Pedro	.03	25.30	
Santa Ana	S. P. R. R.	Firestone Park to Dyer		31.03	
Santa Paula	S. P. R. R.	Montalvo to Saugus		45.42	
Tustin	S. P. R. R.	Tustin Jct. to Tustin		10.65	
Westmorland	S. P. Co.	Calipatria to Westmorland		12.79	
Total Branches					261.37
Total Los Angeles Division					680.58

SPEED OF TRAINS REGULATED BY ORDINANCE THROUGH CITY LIMITS

PAGE	BETWEEN	PSGR. mph	FRT. mph	Lgt. Eng. mph
2, 3	Santa Barbara, over street crossings	20	20	20
2, 3	Ventura station and M.P. 397.09	25	20	20
6	Santa Paula	15	15	15
2, 3, 4 5, 9	Los Angeles, along longitudinal streets No. Spring, No. Main, Alameda and College Sts. to 25th St.	10	10	10
4, 5	Los Angeles, when entering any highway crossing:			
	(1) Main St., Alhambra Ave., Soto St. to Main St.	15	15	15
	(2) East city boundary to Soto St.	25	25	25
4, 5	El Monte, all streets	40	40	35
4, 5	Pomona, 2640 feet each side station	40	40	35
4, 5	M.P. 536.2 (Rialto), Riverside Ave.	30	30	30
4, 5	Colton, all streets	30	30	30
4	South Pasadena, all streets	15	15	15
4	Pasadena, all streets	20	20	20
4	Covina branch, Pomona junction switch and 1161 feet west	15	15	15
9	Vernon, 783 feet east of Clement Jct. and Slauson Ave. (9340 feet)	12	12	12
9	Compton, across Main St.	8	8	8
9	Compton, across Myrrh, Orange and Olive Sts.	20	20	20

MAXIMUM SPEED PERMITTED WHEN HANDLING CERTAIN EQUIPMENT

PAGE		MPH
	Trains handling wooden pile-drivers; locomotive cranes with boom disconnected and heavy end forward; steam shovels and ditchers, transported on their own wheels; and car-top ditchers when blocking and tie-down cables are removed:	
All	On tangent main tracks	35
	except SPMW 4044	25
All	On tangent branch tracks	25
All	On all curves.....5 MPH less than speed authorized. Where slow boards in place 5 MPH less than shown on slow boards, except when speed indicated is 15 MPH or less be governed by slow boards.	
	Trains handling locomotive cranes with boom disconnected and light end forward (must not be handled in this manner except in emergency):	
All	On tangent main tracks	20
All	On curves and on branch tracks	15
	Trains handling locomotive cranes with boom in place, either end forward (to be handled in work trains when practicable):	
All	On tangent main tracks	25
All	On curves and on branch tracks	15
All	Trains handling steel pile-drivers may make maximum freight train speed.	
	Trains handling relief outfit with steam derrick:	
All	On tangent main tracks	35
All	On tangent branch tracks	25
All	On all curves.....5 MPH less than speed authorized. Where slow boards in place 5 MPH less than shown on slow boards, except where speed indicated is 15 MPH or less be governed by slow boards.	
	Through interlockings with caution.	

Passenger trains handling steel wheel box cars or foreign line steel wheel box cars equipped for movement in passenger trains, except those equipped with high speed trucks, must not exceed speed of 60 MPH.

Baggage and Express cars in Series 5800-5874 are not equipped with high speed trucks. Trains handling them must not exceed 60 MPH.

SPEED RESTRICTIONS FOR OTHER THAN MAIN TRACKS	With Caution Not Exceeding MPH
Through sidings, yard and other side-tracks, crossovers, turnouts and slip-switches, except:	15
Entering Alameda St. from Finkelstein Foundry Co., spur MP 490.3 San Pedro Branch (crossing must be cleared as quickly as practicable)	6
On Limoneria spur, Limco, on tangent running forward	25
" on tangent backing	20
" on curves	10
On VC yard tracks, Oxnard, when shoving	10
Between River Station and Mission Tower	10
MP 480.37 and River Station Tower	20
Through any siding, crossover, turnout, or slip-switch with engine backing	10

*LIST OF CCB (CROSS COUNTER-BALANCED) ENGINES:

All P-8 class, except Eng. 2470;

F-1 class: 3611, 3612, 3615, 3616, 3619, 3620, 3625, 3634, 3636, 3638, 3643, 3647, 3652;

F-3 class: 3653, 3654, 3655, 3656, 3657, 3658, 3660, 3661, 3662, 3663, 3664, 3665, 3666;

F-4 class: 3668, 3670, 3671, 3672, 3674, 3676, 3677, 3678, 3681, 3682, 3683, 3684, 3685, 3686, 3687, 3688, 3692, 3695, 3696, 3697, 3701, 3702, 3704, 3705, 3706, 3707, 3709, 3711, 3715, 3716, 3717;

F-5 class: 3718, 3720, 3721, 3727, 3728, 3732, 3734, 3737, 3742, 3752, 3753, 3755, 3760, 3763, 3764, 3765, 3766, 3767, 3768, 3769;

AC-6 class: 4126, 4127, 4128, 4130, 4131, 4132, 4133, 4135, 4136, 4137, 4138, 4140, 4142, 4143, 4144, 4146, 4149, 4150;

SP-1 class: 5001, 5002, 5003, 5006, 5008, 5009, 5011, 5012, 5013, 5014, 5015;

SP-2 class: 5016, 5017, 5018, 5019, 5020, 5021, 5022, 5023, 5024, 5025, 5026, 5027, 5028, 5029, 5031, 5032, 5033, 5034, 5035, 5038;

SP-3 class: 5039, 5040, 5041, 5042, 5043, 5044, 5045, 5047, 5048.

MAXIMUM SPEED PERMITTED CERTAIN ENGINES, SUBJECT TO FURTHER RESTRICTIONS AS SHOWN IN SPEED RESTRICTIONS TABLE

Maximum speed for SP-1-2-3 not cross counter-balanced, C-15-17-32, Mk-10-11 and MM-3 class engines 35 MPH when handling Freight and Mixed Trains.

Maximum speed for S and SE class engines, 20 MPH, but must not exceed speed permitted Freight and Mixed Trains and Light Engines.

Maximum speed for Gas-electric cars running light forward, 50 MPH, but must not exceed speed permitted when handling Passenger Trains.

Engines backing must not exceed 20 MPH on all curves, and when approaching road crossings at grade.

Engines coupled tender to tender must not exceed speed permitted same engines running light backward.

Engines with tenders having water capacity 7,000 gallons or less, except Classes 70-R-1 and 70-SC-1, must not exceed 50 MPH.

Maximum speed for light engines running forward on branches when not otherwise shown will be same as maximum for freight trains.

AC class engines must not exceed 45 MPH over the following structures:

MP 372.75 over highway east of Santa Barbara
MP 374.24 west of Miramar
MP 381.55 Carpinteria
MP 396.87 Ventura River bridge, Ventura

Diesel electric switch engines running forward, with train or light, may make maximum speed as shown below, except must not exceed speed permitted Freight and Mixed trains. These engines when backing may make speed shown below, except must not exceed speed permitted E class engines backing where such permitted speed is less than 30 MPH:

Classification	Running Forward With Train	Light	Running Backward With Train or Light
DES-200	30	30	30
DES-1 to 7 inc	40	40	40
DES-100 to 107 inc	40	40	40

Maximum speed of engines under following conditions running under own steam or hauled in train, must not exceed:

When all weight has been removed from any one pair of drivers	20 MPH
When all weight has been removed from only one wheel from any pair of drivers	30 MPH
When engine truck is removed	20 MPH
When main rod only is removed	30 MPH
When side rod only is removed	30 MPH
When both main and side rods are removed	20 MPH
When hauled in train with all rods on	30 MPH

Within the limits of Burbank Jct. interlocking, speed of westward trains via Mojave Subdivision restricted as follows:

Passenger	35 MPH
Freight	25 MPH
Light engines	20 MPH

Trains consisting of streamlined cars, when handled by other than GS class engines, must not exceed speed prescribed for type of power used.

SPEED RESTRICTIONS: Maximum speed of Passenger trains must not exceed 50 MPH and Freight and Mixed trains 35 MPH except as otherwise provided for herein, or by bulletin, train order or "fixed signal."

Maximum speed of any train with an engine not shown in Speed Restriction table, 35 MPH, and is further restricted to Maximum speed shown for Freight and Mixed trains if less than 35 MPH.

Page No.	TERRITORY	WITH TRAIN — ENGINE RUNNING FORWARD										LIGHT ENGINE RUNNING FORWARD				ENGINE BACKING WITH TRAIN OR LIGHT	
		PASSENGER															
		GS P (if CCB*) with streamlined cars only	P-8 (if CCB*) P-7-10-12 GS Mt	E A P-1-3-4-5-6-11 P-8 (if not CCB*)	T -26 -32 -37 -40	AC-4-5-7-8-9-10-11-12 AC-8 (if CCB*)	T-1-8-9-23-28-31-36-57-58 Mk-5-6-7-8-9 F (if CCB*) SP (if CCB*) Gas-elec. cars	M AM-2	C-2-4-5-8-9-10-18-19-26-27-28-29 Mk-2-4, TW F (if not CCB*) AC-1-2-3-6 (if not CCB*)	C-15-17-32 Mk-10-11 MM-3 SP (if not CCB*)	FREIGHT AND MIXED	E P A Mt GS	T-26-32-37-40 F (if CCB*)	M T-1-8-9-23-28-31-36-57-58 C-2-4-5-8-9-10-18-19-26-27-28-29 Mk-5-6-7-8-9 F (if not CCB*) SP	C-15-17-32 TW Mk-2-4-10-11 AC AM-2 MM-3	E A T P C TW Mk F Mt GS SP	M AC AM-2 MM-3 Gas-elec. cars
2, 3	Santa Barbara - Mission Tower via Raymer except	75	65	65	60	50	50	45	40	35	40	35	35	35	30	30	25
	MP 370.70 - MP 383.66	50	50	50	50	50	50	45	40	35	35	35	35	35	30	30	25
	MP 383.66 - MP 387.70 Eastward	45	45	45	45	45	45	45	40	35	35	35	35	35	30	30	25
	Westward	45	45	45	45	45	45	45	40	35	35	30	30	30	30	30	25
	MP 387.70 - MP 400.00	65	60	60	60	50	50	45	40	35	40	35	35	35	30	30	25
	MP 407.50 - MP 408.00	25	25	25	25	25	25	25	25	25	20	25	25	25	25	20	20
	MP 418.00 - MP 437.80	65	60	60	60	50	50	45	40	35	40	30	30	30	30	30	25
	MP 437.80 - MP 440.90	60	60	60	60	50	50	45	40	35	35	35	35	35	30	30	25
	MP 440.90 - MP 444.39	40	40	40	40	40	40	40	40	35	30	30	30	30	30	30	25
	MP 462.38 - MP 462.70 Eastward	40	40	40	40	40	40	40	40	35	30	30	30	30	30	30	25
	Westward	35	35	35	35	35	35	35	35	35	30	30	30	30	30	30	25
	Through Crossover Burbank Jct. east of tower	30	30	30	30	30	30	30	30	30	25	25	25	25	25	25	25
	MP 462.70 - MP 475.88	50	50	50	50	45	45	45	40	35	35	35	35	35	30	30	25
	MP 475.88 - MP 476.35	50	50	50	50	45	45	45	40	35	30	30	30	30	30	30	25
	MP 476.35 - MP 477.34	50	50	50	50	50	50	45	40	35	35	35	35	35	30	30	25
	MP 477.34 - MP 480.37	40	40	40	40	40	40	40	40	35	25	25	25	25	25	25	25
	Through switches, MP 478.98 and MP 480.60	25	25	25	25	25	25	25	25	25	20	20	20	20	20	20	20
	Dayton Ave. Tower - East Bank Jct	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20
	East Bank Jct. - Mission Tower	10	10	10	10	10	10	10	10	10	10	10	10	10	10	10	10
	East Bank Jct. - Taylor Jct	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15	15
4, 5, 6, 8, 9	Mission Tower - Yuma except		50	50	50	50	50	45	40	35	35	35	35	35	30	30	25
	Mission Tower - Taylor Jct		15	15	15	15	15	15	15	15	15	15	15	15	15	15	15
	Through turnout end double track Alhambra		25	25	25	25	25	25	25	25	25	25	25	25	25	20	20
	MP 491.20 - MP 536.35 except		65	65	60	50	50	45	40	35	40	35	35	35	30	30	25
	Through city limits, Ontario		40	40	40	40	40	40	35	35	40	35	35	35	30	30	25
	MP 536.65 - MP 539.00		30	30	30	30	30	30	30	30	30	30	30	30	30	30	25
6	MP 539.00 - MP 540.00		20	20	20	20	20	20	20	20	20	20	20	20	20	20	20
	MP 540.00 - MP 546.64 Westward		50	50	50	50	50	45	40	35	25	35	35	35	30	25	25
	MP 546.64 - MP 563.35 Eastward		40	40	40	40	40	40	40	35	35	35	35	35	30	30	25
	Westward		40	40	40	40	40	40	40	35	25	35	35	35	30	25	25
	MP 563.35 - MP 567.60 Eastward		50	50	50	50	50	45	40	35	20	35	35	35	30	20	20
	MP 567.60 - MP 589.00 Eastward		40	40	40	40	40	40	40	35	20	35	35	35	30	20	20
	Westward		40	40	40	40	40	40	40	35	35	35	35	35	30	30	25
	MP 589.00 - MP 598.55 Eastward		50	50	50	50	50	45	40	35	25	45	40	35	30	25	25
6, 8, 9	MP 609.70 - Indio Yard train order office		20	20	20	20	20	20	20	20	20	20	20	20	20	20	20
	Indio Yard train order office - East switch East Indio		30	30	30	30	30	30	30	30	20	20	20	20	20	20	20
8, 9	East switch East Indio - MP 678.5		50	50	50	50	50	45	40	35	35	45	40	35	30	30	25
	Through all switches Araz Jct		25	25	25	25	25	25	20	20	25	20	20	20	20	20	20
	Westward on Eastward Track over I-C Ry. junction switch		20	20	20	20	20	20	20	20	20	20	20	20	20	20	20
	Through Crossovers, Araz		25	25	25	25	25	25	20	20	25	20	20	20	20	20	20
	MP 727.00 - MP 731.75		60	60	60	50	50	45	40	35	35	45	40	35	30	30	25
	MP 731.75 - Yuma		15	15	15	15	15	15	15	15	15	15	15	15	15	15	15

Page No.	TERRITORY	PSGR.	FRT.	Engines Backing
		Maximum	Freight and Mixed Maximum	
4	Covina Branch	30	25	25
4	Pasadena Branch	15	15	15
5	Chino Branch	20	20	20
5	Riverside Branch, except	35	20	20
	Through Highgrove interlocking	20	20	20
6	Ojai Branch, except	25	20	20
	MP 407.00 - MP 408.00	10	10	10
6	Santa Paula Branch, except	30	25	25
	MP 414.06 - MP 414.20	30	18	18
	MP 431.62 - MP 438.10	25	18	15
	MP 439.05 - MP 439.41	25	18	15
	MP 440.93 - MP 441.96	25	18	15
	MP 444.20 - MP 444.84	30	18	18
6	Redlands Branch, except	25	20	20
	Redlands 2nd St. over all street crossings	10	10	10
7	Long Beach Branch, except	40	25	25
	PERy crossing - Anaheim Blvd	10	10	10
7	Santa Ana Branch, except	30	30	25
	Through Southgate interlocking	20	20	20
	West Anaheim - 1 mile east of Anaheim	15	15	15
	Santa Ana, between 3208 feet west and 2132 feet east of station bldg	12	12	12
	Santa Ana - Dyer	30	25	25
7	Los Alamitos Branch, except	20	20	20
	Stanton Jct. - Los Alamitos	10	10	10
7	Smeltzer Branch	20	20	20
7	Tustin Branch, except	30	30	20
	Over bridge 513-D	20	20	20
	MP 516.30 - MP 516.41	20	20	20
	MP 517.73 - MP 518.25	20	20	20
	MP 518.70 - MP 518.92	20	20	20
	MP 519.23 - MP 519.86	20	20	20
	MP 521.60 - MP 521.73	20	20	20
7	Niland - Calexico, except	35	35	25
	Niland station - wye switch	20	20	20
	Over Alamo bridge, MP 679.85	30	30	25
	Over Main St. crossing, El Centro	20	20	20
7	Westmorland Branch	25	25	25
7	Sandia Branch	25	25	25
8	Burbank Branch, except	25	25	25
	Over Balboa Blvd. crossing, Encino	10	10	10
9	Firestone Park - San Pedro, except	30	30	25
	Through Nadeau interlocking	10	10	10
	Wilmington (Anaheim Blvd) - Fifth St. San Pedro	15	15	15
7-9	Crossover switches - station building, Firestone Park	15	15	15

RATING OF ENGINES—LOS ANGELES DIVISION—In Ms of 1000 lbs. Back of Tender.

NOMINAL CLASS	ENGINE NUMBERS	Los Angeles to Alhambra Puente to Ontario	Alhambra to Puente Ontario to Colton	Colton to Bloomington El Monte to Stoneman	Bloomington to El Monte Stoneman to Los Angeles	Colton to Indio	Indio to Colton	Niland to Amos Yuma to Araz Jct. Enroute I-C	Yuma to Knob	Indio to Niland Amos to Yuma Knob to Indio	Niland and Calexico	Burbank Jct. to Saugus	Saugus to Burbank Jct.	Saugus to Montalvo	Montalvo to Saugus	Los Angeles and Santa Barbara Via Oxnard L. A. Yard to 47th St. Via River Station	47th St. to L. A. Yard Via Butte St. and East Bank	San Pedro to 47th St.	L. A. Yard to San Pedro Via East Bank and 47th St.	47th St. to L. A. Yard Via River Station	Alhambra to Pasadena Ventura Jct. to Ojai	Burbank to Chatsworth Via Burbank Branch
DES-1,2,3,4,5,6,7	1000 to 1022	1000	1800	1600	2150	500	500	1600	1600	1500	1850	400	450	4500	1700	1000	1700	1800	2600	1800	700	800
DES-100 to 107	1300 to 1395	1600	2850	2500	3200	850	800	2500	2500	2500	2900	650	700	5700	2200	1600	2600	2850	3000	2800	850	1500
E-23	1500 and 1502	1200	2700	1450	2600	690	660	1750	1600	2600	2300	510	580	4000	1340	1300	1950	2800	2950	2750	380	950
M-4	1617 to 1713	1600	3450	1850	3350	940	900	2250	2100	3300	2900	730	820	5300	1800	1700	2500	3400	3900	3600	570	1300
M-6, 8	1721 to 1803, 1823 to 1825	2000	4250	2300	4150	1200	1150	2800	2600	4050	3600	930	1000	6200	2140	2150	2900	4000	4550	4350	700	1550
M-9, 11	1804 to 1822, 1826 to 1831 and 1836	2100	4500	2450	4300	1250	1200	2900	2750	4300	3800	990	1100	6550	2270	2250	3000	4200	4800	4600	760	1650
M-11	1832 to 1835	2150	4600	2550	4450	1300	1250	3050	2800	4450	3950	1000	1120	6800	2370	2350	3350	4750	5000	4800	790	1700
T-1	2242 to 2271	1400	3050	1650	2950	830	800	2000	1850	2950	2600	630	710	4500	1556	1500	2200	3150	3300	3100	490	1100
T-8, 9	2161, 2174 and 2178	1000	2200	1150	2100	560	550	1400	1300	2100	1850	420	480	3250	1090	1050	1550	2250	2400	2200	320	770
T-23	2301 to 2310	2100	4500	2450	4300	1250	1200	2900	2750	4300	3800	930	1030	6500	2240	2250	3000	4200	4800	4500	730	1600
T-26	2283 to 2299	1750	4000	2050	3650	1000	950	2500	2300	3600	3250	800	900	5700	1950	1900	2600	3700	4200	4000	610	1400
T-28, 31	2311 to 2362	2300	4850	2700	4700	1350	1250	3250	3000	4700	4150	1050	1200	7150	2480	2450	3300	4650	5250	5000	820	1800
T-32, 40	2363 to 2384	2300	4950	2700	4750	1350	1300	3300	3000	4750	4200	1050	1200	7250	2520	2450	3600	5100	5350	5100	830	1830
T-36	2103	1500	3250	1800	3150	910	890	2150	2000	3150	2750	710	780	4880	1670	1650	2350	3350	3550	3400	560	1220
T-37	2105 and 2106	2050	4400	2400	4250	1200	1150	2900	2700	4250	3750	940	1050	6500	2250	2200	3200	4550	4800	4500	740	1630
T-57, 58	2385 and 2386	1850	3950	2150	3850	1100	1050	2650	2400	3850	3400	850	900	5850	2000	2000	2900	4100	4300	4100	670	1470
P-1, 3, 5	2408, 2411, 2412, 2413, 2416, 2417, 2418 2423, 2425 to 2435 2437 to 2452, 2459 and 2460	1800	4200	2100	4050	1000	1000	2550	2350	3750	3350	800	890	5900	1980	1950	2700	3800	4300	4050	590	1410
P-1	2400, 2403 to 2407 and 2415	1900	4400	2200	4250	1050	1050	2650	2450	3900	3500	840	930	6150	2080	2050	2850	4050	4500	4200	620	1480
P-4	2401, 2402, 2409, 2410, 2414, 2419, 2420, 2422, 2424 and 2436	2050	4600	2400	4350	1150	1100	3050	2850	4300	3800	900	1100	6450	2180	2250	2950	4150	4700	4450	660	1560
P-6	2453, 2454 and 2458	2250	5200	2600	5100	1300	1250	3200	2950	4650	4150	1000	1150	7250	2480	2500	3550	....	5350	5000	....	....
P-7	2476 and 2477	2400	5450	2800	5400	1400	1300	3400	3150	4950	4400	1100	1250	7700	2660	2650	3800	....	5700	5300	....	....
P-8, 10	2461 to 2474, 2478 to 2483	2500	5600	3000	5450	1450	1400	3600	3300	5200	4650	1100	1250	8050	2720	2750	3900	....	5900	5500	....	....
P-8, 10	2475, 2484 to 2491	2600	5600	3100	5750	1450	1400	3900	3600	5400	4850	1100	1250	8500	2880	2850	4150	....	6200	5800	....	....
P-11	3100 to 3109	2000	4250	2300	4150	1200	1150	2800	2600	4050	3600	850	950	6300	2150	2150	2900	4000	4650	4300	660	1540
P-12	3120 to 3129	2600	6050	3050	5450	1550	1500	3700	3450	5450	4850	1200	1350	8500	2870	2950	4150	....	6200	5800	....	....
C-5,8,9,10,26 to 29	2513 to 2599, 2624 to 2860, 3440 to 3469	2550	5300	2950	5200	1550	1500	3600	3300	5200	4600	1200	1300	7800	2700	2700	3900	5500	5800	5350	911	1980
C-15, 32	2500, 2505 to 2507	1600	3400	1850	3300	960	930	2250	2100	3300	2900	740	820	5000	1750	1700	2500	3500	3700	3450	590	1280
C-17	2510 and 2511	2000	4200	2300	4050	1200	1150	2800	2600	4050	3600	950	1050	6150	2180	2150	3050	4350	4550	4250	750	1600
C-18	3400 to 3409	2300	4900	2700	4750	1400	1350	3250	3000	4750	4200	1100	1200	7200	2530	2500	3600	5050	5300	4950	870	1850
C-19	3410 to 3426	2400	5100	2800	4950	1450	1400	3400	3150	4950	4350	1100	1250	7500	2630	2600	3700	5250	5550	5200	890	1920
TW-1	2900 to 2913	1900	4050	2250	3950	1150	1100	2700	2500	3950	3450	890	980	6000	2090	2050	2950	4200	4400	4100	700	1520
TW-2, 3	2932 to 2952	1500	3250	1800	3150	900	870	2150	2000	3150	2800	690	770	4800	1670	1650	2350	3350	3550	3300	540	1200
TW-4, 6	2926 to 2931 and 2957	1450	3100	1700	3000	840	810	2050	1850	3000	2650	640	720	4550	1570	1550	2250	3200	3350	3150	500	1130
TW-8	2914 to 2923	2100	4500	2450	4350	1250	1200	3000	2750	4350	3850	980	1050	6600	2300	2250	3250	4650	4900	4550	770	1680
A-3	3029	1400	3100	1650	3000	780	760	2050	1850	3000	2650	580	650	4650	1540	1500	2250	3250	3600	3150	430	1090
A-3	3025, 3036, 3052 and 3057	1450	3250	1750	3150	820	790	2150	1950	3150	2800	600	690	4900	1620	1600	2350	3400	4150	3350	440	1140
A-6	3000 to 3003	1750	3800	2050	3700	990	950	2500	2300	3700	3250	700	800	5700	1900	1850	2750	3950	6500	3850	560	1350
Mk-2, 4	3201 to 3240	3000	6150	3500	5950	1700	1650	4100	3700	5950	5250	1300	1400	8850	3050	3200	4350	....	....	6100	....	....
Mk-5, 6	3241 to 3277	3200	6750	3700	6500	1850	1800	4500	4100	6500	5750	1450	1600	10000	3470	3500	4950	....	....	6900	....	....
Mk-7, 8, 9	3300 to 3324	3550	7450	4100	7200	2100	2050	4950	4550	7200	6350	1650	1850	10900	3830	3750	5400	....	....	7550	....	....
Mk-10	3295	2700	5750	3150	5550	1600	1550	3850	3500	5550	4900	1250	1400	8400	2960	2900	4200	....	....	5800	....	....
Mk-11	3297 and 3298	2600	5500	3050	5350	1550	1500	3700	3400	5350	4700	1200	1350	8050	2840	2800	4000	....	....	5550	....	....
F-1	3600 to 3652	3750	7750	4350	7600	2300	2250	5250	4850	7600	6700	1750	1950	11300	3950	3950	5600	....	....	7800	....	....
F-3	3653 to 3667	4250	8400	4950	7800	2700	2600	6000	5500	10000	7600	2000	2200	13000	4580	4500	6500	....	....	9000	....	....
F-4, 5	3668 to 3769	4500	8850	5350	8000	2700	2600	6600	6050	11000	8000	2100	2300	13700	4810	4800	6800	....	....	9450	....	....
AM-2	3900 to 3911	4200	8850	4900	8600	2500	2400	5900	5450	8600	7500	1950	2150	13000	4560	4500	6450	....	....	9000	....	....
MM-3	3930 and 3931	5000	10300	5900	8900	3000	2900	7100	6550	10200	8800	2250	2450	15100	5290	5300	7500	....	....	10400	....	....
AC-1, 2, 3	4000 to 4048	4800	9950	5550	9750	3150	3050	6700	6200	11900	8600	2500	2700	15700	5540	5500	8000	10950	11600	10800	....	....
AC-4, 5	4100 to 4125	7750	13900	8750	13150	4000	3850	9450	8700	16500	12000	3200	3500	20500	7230	6900	10200	....	....	14200	....	....
AC-6 to 12	3800 to 3811, 4126 to 4294	8250	14800	9300	14500	4250	4100	10000	9250	18000	14000	3400	3700	....	....	7300	10800	....	....	15000	....	....
Mt-1, 3, 4, 5	4300 to 4376	3500	7450	4100	7250	2050	2000	5250	4850	8800	6500	1550	1750	10700	3670	3850	5250	....	....	7350	....	....
Mt-2	4385 to 4390	3600	7700	4200	7350	2100	2050	5250	4950	9000	6650	1600	1800	11500	3990	3900	5700	....	....	7950	....	....
GS-1, 2	4400 to 4415	3700	8000	4450	7400	2250	2200	5500	5100	9200	6900	1600	1800	11500	3880	3950	5600	....	....	7900	....	....
GS-3, 4, 5, 6	4416 to 4469	3800	8250	4450	7600	2250	2200	5650	5250	9500	7100	1650	1850	12100	4090	4100	5900	....	....	8300	....	....
SP-1, 2, 3	5000 to 5048	5200	10500	6200	9000	3000	2900	7400	6950	11900	9000	2300	2500	19400	5390	5500	7650	....	....	10600	....	....
Allowance for Empty and Underloaded Cars	Less than 45 M's	3	3	3	3	3	3	6	6	6	6	3	3	3	6	6	6	6	6	6	3	
	45 M's to 55 M's	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
	More than 55 M's	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

ENGINES FOR WHICH NO RATING IS SHOWN IN THE RATING OF ENGINES TABLE WILL NOT BE PERMITTED TO OPERATE IN THAT TERRITORY UNLESS AUTHORIZED BY SUPERINTENDENT.

RATING OF ENGINES—LOS ANGELES DIVISION—In Ms of 1000 lbs. Back of Tender.

NOMINAL CLASS	ENGINE NUMBERS	Bryn Mawr to Crafton	Tustin and Tustin Jct.	Los Alamitos to West Anaheim	Wilmington (Anaheim Blvd.) and Long Beach	Westmorland Calipatria and El Centro Via Holtville	Chino to Pomona Wintersburg to Stanton Jct.	Firestone Park and Dyer	La Verne to Bassett Colton to Riverside La Verne to Pomona Pasadena to Alhambra Ojai to Ventura Jct. Crafton to Bryn Mawr West Anaheim to Los Alamitos Chatsworth to Burbank Via Burbank Branch Pomona to Chino Stanton Jct. to Wintersburg	Bassett to La Verne Riverside to Colton	Pomona to La Verne
DES-1,2,3,4,5,6,7	1000 to 1022	550	1500	2250	2000	2600	2200	2600	2600	1050	1150
DES-100 to 107	1300 to 1395	650	1750	2600	2400	3000	2800	3000	3000	1200	1600
E-23	1500 and 1502	250	1040	1860	1750	2300	1340	2750	4000	690	540
M-4	1617 to 1713	400	1400	2400	2300	3000	1800	3600	5300	970	770
M-6, 8	1721 to 1803, 1823 to 1825	500	1680	2900	2760	3580	2140	4350	6200	1100	930
M-9, 11	1804 to 1822, 1826 to 1831 and 1836	550	1790	3100	2900	3790	2270	4600	6550	1200	1000
M-11	1832 to 1835	570	1870	3200	3050	3950	2370	4800	6800	1290	1040
T-1	2242 to 2271	340	1200	2100	2000	2600	1556	3100	4500	830	660
T-8, 9	2161, 2174 and 2178	210	840	1500	1400	1800	1090	2200	3250	560	440
T-23	2301 to 2310	520	1760	3070	2880	3750	2240	4500	6500	1200	970
T-26	2283 to 2299	430	1500	2680	2500	3270	1950	4000	5700	1040	826
T-28, 31	2311 to 2362	590	1950	3390	3200	4100	2480	5000	7150	1350	1087
T-32, 40	2363 to 2384	600	1990	3450	3250	4220	2520	5100	7250	1370	1100
T-36	2103	400	1320	2280	2150	2790	1670	3400	4800	910	730
T-37	2105 and 2106	530	1770	3080	2900	3770	2250	4500	6500	1200	980
T-57, 58	2385 and 2386	480	1600	2770	2600	3400	2000	4100	5850	1100	880
P-1, 3, 5	2408, 2411, 2412, 2413, 2416, 2417, 2418 2423, 2425 to 2435 2437 to 2452, 2459 and 2460	400	1540	2740	2580	3370	1980	4050	5900	1040	810
P-1	2400, 2403 to 2407 and 2415	420	1620	2880	2700	3540	2080	4200	6150	1090	850
P-4	2401, 2402, 2409, 2410, 2414, 2419, 2420, 2422, 2424 and 2436	450	1690	3010	2840	3700	2180	4450	6450	1140	900
P-6	2453, 2454 and 2458	....	....	....	....	....	....	....	....	....	....
P-7	2476 and 2477	....	....	....	....	....	....	....	....	....	....
P-8, 10	2461 to 2474, 2478 to 2483	....	....	....	....	....	....	....	....	....	....
P-8, 10	2475, 2484 to 2491	....	....	....	....	....	....	....	....	....	....
P-11	3100 to 3109	460	1680	2960	2790	3630	2150	4350	6300	1140	900
P-12	3120 to 3129	....	....	....	....	....	....	....	....	....	....
C-5,8,9,10,26 to 29	2513 to 2599, 2624 to 2860, 3440 to 3469	660	2140	3710	3500	4500	2720	5500	7800	1480	1190
C-15, 32	2500, 2505 to 2507	430	1380	2390	2260	2920	1750	3550	5000	960	770
C-17	2510 and 2511	560	1720	2950	2790	3600	2180	4400	6150	1200	980
C-18	3400 to 3409	640	2000	3400	3250	4190	2530	5100	7200	1400	1130
C-19	3410 to 3426	650	2080	3580	3380	4370	2630	5300	7500	1400	1173
TW-1	2900 to 2913	510	1650	2850	2690	3480	2090	4200	6000	1145	920
TW-2, 3	2932 to 2952	390	1310	2280	2150	2790	1670	3400	4800	900	720
TW-4, 6	2926 to 2931 and 2957	350	1230	2160	2030	2640	1570	3200	4550	840	670
TW-8	2914 to 2923	560	1820	3140	2970	3847	2300	3650	6600	1260	1010
A-3	3029	270	1190	2150	2020	2660	1540	3150	4650	780	600
A-3	3025, 3036, 3052 and 3057	290	1240	2260	2120	2790	1620	3300	4900	820	630
A-6	3000 to 3003	370	1480	2640	2490	3250	1900	3900	5700	990	770

ENGINES FOR WHICH NO RATING IS SHOWN IN THE RATING OF ENGINES TABLE WILL NOT BE PERMITTED TO OPERATE IN THAT TERRITORY UNLESS AUTHORIZED BY SUPERINTENDENT.

TERMINAL SUPERINTENDENT

W. K. HANNUM.............Los Angeles Yard

ASST. TERMINAL SUPERINTENDENTS

W. A. SEAL.................Los Angeles Yard
W. R. MORLEY.............Los Angeles Yard

TRAINMASTERS

R. D. WORKMAN...........Los Angeles Yard
H. G. HARVEY.............Los Angeles Yard
B. W. BISHOP........................Niland
C. G. HOLMBERG.....................Indio
M. R. HARRINGTON..................Colton
D. P. BOYKIN.......................Saugus

ASSISTANT TRAINMASTERS

H. A. TEAL..................Los Angeles Yard
J. J. HUNTER...............Los Angeles Yard
T. J. BAILEY................Los Angeles Yard
H. E. SUMNER.............Los Angeles Yard

ASSISTANT TRAINMASTER— DIVISION EXAMINER

W. C. PRYOR............Los Angeles Yard

ROAD FOREMEN OF ENGINES

A. C. YOUNG..................Los Angeles
J. T. CANTY...................Los Angeles

CHIEF TRAIN DISPATCHER

F. A. FLANAGAN..............Los Angeles

A. S. McCANN,
Assistant Superintendent.

E. J. KELLUM,
Assistant Superintendent.

M. A. NUGENT,
Assistant Superintendent.


C A L I F O R N I A
K E R N
V E N T U R A
S A N T A   B A R B A R A
L O S   A N G E L E S
S A N   B E R N A R D I N O
O R A N G E
R I V E R S I D E
S A N   D I E G O
I M P E R I A L
M E X I C O
LOWER CALIFORNIA
SONORA
P A C I F I C   O C E A N
SANTA BARBARA CHANNEL
SAN PEDRO CHANNEL
SANTA CATALINA
SANTA CRUZ
SAN NICHOLAS
SEQUOIA NAT'L. FOREST
LOS PADRES NATIONAL FOREST
ANGELES NATIONAL FOREST
CLEVELAND NATIONAL FOREST
SUNSET OIL FIELDS
McKITTRICK OIL FIELDS
TEHACHAPI MOUNTAINS
SAN BERNARDINO MOUNTAINS
SAN JACINTO MOUNTAINS
SANTA ROSA MOUNTAINS
CHUCKAWALLA MTS
CHUCKAWALLA VALLEY
CHOCOLATE MOUNTAINS
SALTON SEA
ALL AMERICAN CANAL
COLORADO RIVER
IMPERIAL DAM
BAKERSFIELD
MOJAVE
LOS ANGELES
SAN BERNARDINO
RIVERSIDE
SAN DIEGO
LONG BEACH
SAN PEDRO
SANTA ANA
ELCENTRO
YUMA
SANTA BARBARA
VENTURA
OXNARD
PASADENA
BURBANK
GLENDALE
POMONA
COLTON
INDIO
BRAWLEY
CALEXICO
TIJUANA

LOS ANGELES
AND
ADJACENT TERRITORY

SCALE OF MILES

0 1 2 3 4 5 10 15

MAP
OF THE
LOS ANGELES DIVISION
SOUTHERN PACIFIC COMPANY
AUGUST, 1918.

J.F.M.

SCALE OF MILES

0 5 10 20 30 40

Revised to Jan. 1, 1939

" " Jan. 1, 1941